



**Count on it.**

**Service Manual**

**TIMECUTTER® Service Manual**



Published: June 2020

# Revision History

# Preface

This service manual was written expressly for Toro service technicians. The Toro Company has made every effort to make the information in this manual complete and correct.

Basic shop safety knowledge and mechanical/electrical skills are assumed. The Table of Contents lists the systems and the related topics covered in this manual.

We are hopeful that you will find this manual a valuable addition to your service shop. If you have any questions or comments regarding this manual, please contact us at the following address:

**The Toro Company**  
**RLC/SWS Customer Care Department**  
**8111 Lyndale Avenue South**  
**Bloomington, MN 55420**

The Toro Company reserves the right to change product specifications or make changes to this manual without notice.

# Service Procedure Icons

The following icons appear throughout this Service Manual to bring attention to specific important details of a service procedure.



## Critical Process

This icon is used to highlight:

- Installing safety equipment (shields, guards, seat belts, brakes, and R.O.P.S. components) that may have been removed
- Dimensions or settings that must be maintained for proper machine operation
- A specific fastener tightening sequence
- Component orientation that may not be obvious



## Critical Torque

This icon is used to highlight an assembly torque requirement that is different than what is recommended in the Standard Torque Tables.



## Fluid Specifications

This icon is used to highlight fluid specifications and capacities that are less common, and may not appear on the machine service decal or in the machine *Operator's Manual*.

**Note:** Refer to the service decal on the machine and the machine *Operator's Manual* for commonly used fluid specifications and capacities.

# Table of Contents

Preface .....	3
Chapter 1: Safety .....	1-1
Safety Instructions .....	1-2
Chapter 2: Specifications and Maintenance .....	2-1
Specifications .....	2-2
Torque Specifications .....	2-4
Chapter 3: Troubleshooting .....	3-1
General Troubleshooting .....	3-3
Chapter 4: Engine .....	4-1
General Information .....	4-2
Service and Repairs .....	4-3
Chapter 5: Chassis.....	5-1
General Information .....	5-2
Service and Repairs .....	5-3
Chapter 6: Hydrostatic Drive System.....	6-1
General Information .....	6-2
Service and Repairs .....	6-3
Chapter 7: Mower Deck System .....	7-1
General Information .....	7-2
Service and Repairs .....	7-3
Chapter 8: Electrical System .....	8-1
General Information .....	8-2
Service and Repairs .....	8-3
Appendix A .....	A-1
Electrical Drawing Abbreviations.....	A-2
Electrical Schematic .....	A-3





## Table of Contents

Safety Instructions .....	1-2
Think Safety First .....	1-2

# Safety Instructions



## DANGER



This safety symbol means danger. When you see this symbol, carefully read the instructions that follow. Failure to obey the instructions could cause serious permanent injury, disability, or death.

---



## WARNING



This safety symbol means warning. When you see this symbol, carefully read the instructions that follow. Failure to obey the instructions can result in serious injury.

---



## CAUTION



This safety symbol means caution. When you see this symbol, carefully read the instructions that follow. Failure to obey the instructions can result in minor to moderate injury and/or damage to property or equipment.

---

## Think Safety First

### **Avoid unexpected starting of engine...**

Always turn off the engine, remove the ignition key and disconnect the spark plug wire(s) before cleaning, adjusting, or repair.

### **Avoid lacerations and amputations...**

Stay clear of all moving parts whenever the engine is running. Treat all normally moving parts as if they were moving whenever the engine is running or has the potential to start.

### **Avoid burns...**

Do not touch the engine, muffler, or other components, which may be hot during operation, while the unit is running or shortly after it has been running.

### **Avoid fires and explosions...**

Use extreme care in handling fuel. It is flammable and its vapors are explosive. Extinguish all cigarettes, cigars, pipes, and other sources of ignition. Avoid spilling fuel and never smoke while working with any type of fuel or lubricant. Wipe up any spilled fuel or oil immediately. Never remove the fuel cap or add fuel when the engine is running. Always use approved, labeled containers for storing or transporting fuel and lubricants. Do not add or drain fuel in an enclosed space. Do not store the machine or fuel container where there is an open flame, spark, or pilot light, such as on a water heater or other appliance.

### **Avoid asphyxiation...**

Do not operate an engine in a confined area without proper ventilation.

### **Avoid injury from batteries...**



## Think Safety First (continued)

Battery acid is poisonous and can cause burns. Avoid contact with skin, eyes and clothing. Battery gases can explode. Keep cigarettes, sparks and flames away from the battery.

### **Avoid injury due to inferior parts...**

Use only original equipment parts to ensure that important safety criteria are met.

### **Avoid injury to bystanders...**

Always clear the area of bystanders before starting or testing powered equipment.

### **Avoid injury due to projectiles...**

Always clear the area of sticks, rocks or any other debris that could be picked up and thrown by the powered equipment.

### **Avoid modifications...**

Never alter or modify any part unless it is a factory approved procedure.

### **Avoid unsafe operation...**

Always test the safety interlock system after making adjustments or repairs on the machine. Refer to the Electrical section in this manual for more information.

### **Avoid electrical shock...**

Never touch electrical wires or components while the engine is running. They can be sources of shock. De-energize the system if you are having to do repairs. If testing electrical components ensure you are working in a dry environment.

### **Hydraulic System...**

Release all pressure in the hydraulic system before performing any work on the system. Keep your body and hands away from pin-hole leaks or nozzles that eject hydraulic fluid under high pressure. Do not use your hands to search for leaks. Hydraulic fluid escaping under pressure can have sufficient force to penetrate under the skin and cause serious injury. Seek medical attention right away if hydraulic fluid gets in the skin.

### **Personal Protective Equipment...**

Tie back long hair, and do not wear loose clothing or jewelry. Use appropriate personal protective equipment (PPE) for protecting yourself from potential hazards in the environment in which you will work. Each process outlined in this manual may need different PPE to protect the service person. Use the proper PPE for the task at hand.

### **Tools...**

All tools should be in proper working order. Do not use tools that are broken or in disrepair. Use the proper tool for the proper application.

### **Lifts, Hoists, and Jacks...**

All lifts, hoists, and jacks should be used in accordance with the manufacturer information. Inspect lifts, hoists, and jacks prior to use. Do not overload lifts, hoists, and jacks. Do not work under a suspended load. Ensure chock blocks are used on equipment that can move. Use lifts or jacks and jack stands that are rated to support the total weight of the machine and any attachments. Do not rely on jacks to support the machine. If you are unsure of the operation of any lifts, hoists, and jacks do not use.

### **Fire Extinguishers...**

## Think Safety First (continued)

The proper class of fire extinguisher should be used in case of fire.

**Class A** extinguishers are for ordinary combustible materials such as paper, wood, cardboard, and most plastics. The numerical rating on these types of extinguishers indicates the amount of water it holds and the amount of fire it can extinguish. Geometric symbol (green triangle).

**Class B** fires involve flammable or combustible liquids such as gasoline, kerosene, grease and oil. The numerical rating for class B extinguishers indicates the approximate number of square feet of fire it can extinguish. Geometric symbol (red square).

**Class C** fires involve electrical equipment, such as appliances, wiring, circuit breakers and outlets. Never use water to extinguish class C fires - the risk of electrical shock is far too great! Class C extinguishers do not have a numerical rating. The C classification means the extinguishing agent is non-conductive. Geometric symbol (blue circle).

**ABC** fire extinguishers are a dry chemical type used for multiple purposes. See above information for description. Ensure fire extinguishers are serviceable and replace any that are discharged or out of inspection dates



# Specifications and Maintenance

## Table of Contents

Specifications .....	2-2
Torque Specifications .....	2-4
Equivalents and Conversions.....	2-9
U.S. to Metric Conversions .....	2-10

# Specifications

Model	74685	74687	74690	74694
Deck Size	107 cm (42 inches)			127 cm (50 inches)
Deck Construction	Stamped		Fabricated	
HOC Type	3 Point			
HOC Range	3.81–11.43 cm (1.5-4.5 inches)			
Engine	Toro Single	Toro Twin		
Engine Model	LC1P92F-1 (CE)	LC2P77F	LC2P77F(49 ST)	
Engine Displacement	452cc	708cc		
Engine RPM	2600 ± 100 rpm	2850 ± 100 rpm		
Fuel Tank Cap	11 L (3 gallons)			
Hydro Transaxle	Hydro-Gear ZT-2100			
Suspension	N/A		MYRIDE®	
Bagger Capacity	8 Bushel			
Battery Size	230 CCA			

Model	75742TA	75745TA	75755TA	74710
Deck Size	107 cm (42 inches)		127 cm (50 inches)	81 cm (32 inches)
Deck Construction	Stamped	Fabricated		Stamped
HOC Type	3 Point			
HOC Range	3.81–11.43 cm (1.5-4.5 inches)			
Engine	Toro Twin			Toro Single
Engine Model	LC2P77F	LC2P77F (49 ST)		LC1P92F-1 (DOM,50ST)
Engine Displacement	708cc			452cc
Engine RPM	3300 ± 100 rpm			
Fuel Tank Cap	11 L (3 gallons)			
Hydro Transaxle	Hydro-Gear ZT-2100		Hydro-Gear ZT-2200 Long Axle	Hydro-Gear ZT-2100
Suspension	N/A	MYRIDE®		N/A
Bagger Capacity	8 Bushel			
Battery Size	230 CCA			195 CCA

Model	75740	75741	75742	75743
Deck Size	107 cm (42 inches)			
Deck Construction	Stamped			Fabricated
HOC Type	3 Point			
HOC Range	3.81–11.43 cm (1.5-4.5 inches)			
Engine	Toro Single	Kawasaki Twin	Toro Twin	Kawasaki Twin
Engine Model	LC1P92F-1 (DOM,50ST)	FR600V- S04-R (CARB)	LC2P77F	FR691V-AS26-R

<b>Engine Displacement</b>	452cc	603cc	708cc	726cc
<b>Engine RPM</b>	3300 ± 100 rpm	3250 ± 100 rpm	3300 ± 100 rpm	3250 ± 100 rpm
<b>Fuel Tank Cap</b>	11 L (3 gallons)			
<b>Hydro Transaxle</b>	Hydro-Gear ZT-2100			
<b>Suspension</b>	N/A			MYRIDE®
<b>Bagger Capacity</b>	8 Bushel			
<b>Battery Size</b>	230 CCA			

<b>Model</b>	<b>75745</b>	<b>75750</b>	<b>75751</b>	<b>75753</b>
<b>Deck Size</b>	107 cm (42 inches)	127 cm (50 inches)		
<b>Deck Construction</b>	Fabricated			
<b>HOC Type</b>	3 Point			
<b>HOC Range</b>	3.81–11.43 cm (1.5-4.5 inches)			
<b>Engine</b>	Toro Twin	Kawasaki Twin	Kohler Twin	Kawasaki Twin
<b>Engine Model</b>	LC2P77F(49 ST)	FR691V-_S07-R	PS-KT735-3084	FR691V-AS26-R
<b>Engine Displacement</b>	708cc	726cc	725cc	726cc
<b>Engine RPM</b>	3300 ± 100 rpm			3250 ± 100 rpm
<b>Fuel Tank Cap</b>	11 L (3 gallons)			
<b>Hydro Transaxle</b>	Hydro-Gear ZT-2100			
<b>Suspension</b>	MYRIDE®	N/A		
<b>Bagger Capacity</b>	8 Bushel			
<b>Battery Size</b>	230 CCA			

<b>Model</b>	<b>75755</b>	<b>75754</b>	<b>75757</b>	<b>75759</b>	<b>75760</b>
<b>Deck Size</b>	127 cm (50 inches)	137 cm (54 inches)		127 cm (50 inches)	152 cm (60 inches)
<b>Deck Construction</b>	Fabricated				
<b>HOC Type</b>	3 Point				4 Point
<b>HOC Range</b>	3.81–11.43 cm (1.5-4.5 inches)				
<b>Engine</b>	Toro Twin		Kawasaki Twin		Toro Twin
<b>Engine Model</b>	LC2P77F(49 ST)		FR691V-AS26-R	FR691V-_S07-R	LC2P77F
<b>Engine Displacement</b>	708cc		726cc		708cc
<b>Engine RPM</b>	3300 ± 100 rpm		3250 ± 100 rpm	3300 ± 100 rpm	3600 ± 100 rpm
<b>Fuel Tank Cap</b>	11 L (3 gallons)				
<b>Hydro Transaxle</b>	Hydro-Gear ZT-2200 Long Axle	Hydro-Gear ZT-2200		Hydro-Gear ZT-2200 Long Axle	Hydro-Gear ZT-2800
<b>Suspension</b>	MYRIDE®				N/A
<b>Bagger Capacity</b>	8 Bushel				
<b>Battery Size</b>	230 CCA				

# Torque Specifications

The recommended fastener torque values are listed in the following tables. For critical applications, as determined by Toro, either the recommended torque or a torque that is unique to the application is clearly identified and specified in the service manual.


These torque specifications for the installation and tightening of fasteners shall apply for all fasteners which do not have a specific requirement identified in the service manual. The following factors shall be considered when applying torque: cleanliness of the fastener, use of a thread sealant (Loctite), degree of lubrication on the fastener, presence of a prevailing torque feature, hardness of the surface underneath of the fastener's head, or similar condition which affects the installation.

As noted in the following tables, torque values should be reduced by 25% for lubricated fasteners to achieve the similar stress as a dry fastener. Torque values may also have to be reduced when the fastener is threaded into aluminum or brass. The specific torque value should be determined based on the aluminum or brass material strength, fastener size, length of thread engagement, etc.

The standard method of verifying torque shall be performed by marking a line on the fastener (head or nut) and mating part, then back off fastener 1/4 of a turn. Measure the torque required to tighten the fastener until the lines match up.

## Fastener Identification

### Inch Series Bolts and Screws




g272208

**Figure 1**

1. Grade 1
2. Grade 5
3. Grade 8

## Metric Bolts and Screws



g272209

**Figure 2**

1. Class 8.8

2. Class 10.9

---

## Standard Torque for Dry, Zinc Plated, and Steel Fasteners (Inch Series)

Thread Size	Grade 1, 5, & 8 Fasteners with Thin Height Nuts	SAE Grade 1 Bolts, Screws, Studs & Sems with Regular Height Nuts (SAE Grade 2 or Better Nut)		SAE Grade 5 Bolts, Screws, Studs & Sems with Regular Height Nuts (SAE Grade 5 or Better Nut)		SAE Grade 8 Bolts, Screws, Studs & Sems with Regular Height Nuts (SAE Grade 8 or Better Nut)	
		in-lb	in-lb	N • cm	in-lb	N • cm	in-lb
#6-32 UNC	10 ± 2	13 ± 2	147 ± 23	15 ± 2	169 ± 23	23 ± 3	260 ± 34
#6-40 UNF				17 ± 2	192 ± 23	25 ± 3	282 ± 34
#8-32 UNC	13 ± 2	25 ± 5	282 ± 30	29 ± 3	328 ± 34	41 ± 5	463 ± 56
#8-36 UNF				31 ± 4	350 ± 45	43 ± 5	486 ± 56
#10-24 UNC	18 ± 2	30 ± 5	339 ± 56	42 ± 5	475 ± 56	60 ± 6	678 ± 68
#10-32 UNF				48 ± 5	542 ± 56	68 ± 7	768 ± 79
1/4-20 UNC	48 ± 7	53 ± 7	599 ± 79	100 ± 10	1130 ± 113	140 ± 15	1582 ± 169
1/4-28 UNF	53 ± 7	65 ± 10	734 ± 113	115 ± 12	1299 ± 136	160 ± 17	1808 ± 192
5/16-18 UNC	115 ± 15	105 ± 15	1186 ± 169	200 ± 25	2260 ± 282	300 ± 30	3390 ± 339
5/16-24 UNF	138 ± 17	128 ± 17	1446 ± 192	225 ± 25	2542 ± 282	325 ± 33	3672 ± 373
	ft-lb	ft-lb	N • m	ft-lb	N • m	ft-lb	N • m
3/8-16 UNC	16 ± 2	16 ± 2	22 ± 3	30 ± 3	41 ± 4	43 ± 5	58 ± 7
3/8-24 UNF	17 ± 2	18 ± 2	24 ± 3	35 ± 4	47 ± 5	50 ± 6	68 ± 8
7/16-14 UNC	27 ± 3	27 ± 3	37 ± 4	50 ± 5	68 ± 7	70 ± 7	95 ± 9
7/16-20 UNF	29 ± 3	29 ± 3	39 ± 4	55 ± 6	75 ± 8	77 ± 8	104 ± 11
1/2-13 UNC	30 ± 3	48 ± 7	65 ± 9	75 ± 8	102 ± 11	105 ± 11	142 ± 15
1/2-20 UNF	32 ± 4	53 ± 7	72 ± 9	85 ± 9	115 ± 12	120 ± 12	163 ± 16
5/8-11 UNC	65 ± 10	88 ± 12	119 ± 16	150 ± 15	203 ± 20	210 ± 21	285 ± 28
5/8-18 UNF	75 ± 10	95 ± 15	129 ± 20	170 ± 18	230 ± 24	240 ± 24	325 ± 33
3/4-10 UNC	93 ± 12	140 ± 20	190 ± 27	265 ± 27	359 ± 37	375 ± 38	508 ± 52
3/4-16 UNF	115 ± 15	165 ± 25	224 ± 34	300 ± 30	407 ± 41	420 ± 43	569 ± 58
7/8-9 UNC	140 ± 20	225 ± 25	305 ± 34	430 ± 45	583 ± 61	600 ± 60	813 ± 81
7/8-14 UNF	155 ± 25	260 ± 30	353 ± 41	475 ± 48	644 ± 65	667 ± 66	904 ± 89

**Note:** Reduce torque values listed in the table above by 25% for lubricated fasteners. Lubricated fasteners are defined as threads coated with a lubricant such as oil, graphite, or thread sealant such as Loctite.

Torque values may have to be reduced when installing fasteners into threaded aluminum or brass. The specific torque value should be determined based on the fastener size, the aluminum or base material strength, length of thread engagement, etc.

The nominal torque values listed above for Grade 5 and 8 fasteners are based on 75% of the minimum proof load specified in SAE J429. The tolerance is approximately ± 10% of the nominal torque value. Thin nuts include jam nuts.



## Standard Torque for Dry, Zinc Plated, and Steel Fasteners (Metric Series)

Thread Size	Class 8.8 Bolts, Screws, Studs with Regular Height Nuts (Class 8 or Stronger Nuts)		Class 10.9 Bolts, Screws, Studs with Regular Height Nuts (Class 10 or stronger Nuts)	
	in-lb	N • cm	in-lb	N • cm
<b>M5 X 0.8</b>	57 ± 6	644 ± 68	78 ± 8	881 ± 90
<b>M6 X 1.0</b>	96 ± 10	1085 ± 113	133 ± 14	1503 ± 158
	ft-lb	N • m	ft-lb	N • m
<b>M8 X 1.25</b>	19 ± 2	26 ± 3	28 ± 3	38 ± 4
<b>M10 X 1.5</b>	38 ± 4	52 ± 5	54 ± 6	73 ± 8
<b>M12 X 1.75</b>	66 ± 7	90 ± 10	93 ± 10	126 ± 14
<b>M16 X 2.0</b>	166 ± 17	255 ± 23	229 ± 23	310 ± 31
<b>M20 X 2.5</b>	325 ± 33	440 ± 45	450 ± 46	610 ± 62

**Note:** Reduce torque values listed in the table above by 25% for lubricated fasteners. Lubricated fasteners are defined as threads coated with a lubricant such as oil, graphite, or thread sealant such as Loctite.

Torque values may have to be reduced when installing fasteners into threaded aluminum or brass. The specific torque value should be determined based on the fastener size, the aluminum or base material strength, length of thread engagement, etc.

The nominal torque values listed above are based on 75% of the minimum proof load specified in SAE J1199. The tolerance is approximately ± 10% of the nominal torque value. Thin height nuts include jam nuts.

## SAE Grade 8 Steel Set Screws

Thread Size	Recommended Torque	
	Square Head	Hex Socket
1/4 - 20 UNC	140 ± 20 in-lb	73 ± 12 in-lb
5/16 - 18 UNC	215 ± 35 in-lb	145 ± 20 in-lb
1/2 - 13 UNC	75 ± 15 ft-lb	50 ± 10 ft-lb
3/8 - 16 UNC	35 ± 10 ft-lb	18 ± 3 ft-lb

## Wheel Bolts and Lug Nuts

Thread Size	Recommended Torque**	
7/16 - 20 UNF Grade 5	65 ± 10 ft-lb	88 ± 14 N • m
1/2 - 20 UNF Grade 5	80 ± 10 ft-lb	108 ± 14 N • m
M12 X 1.25 Class 8.8	80 ± 10 ft-lb	108 ± 14 N • m
M12 X 1.5 Class 8.8	80 ± 10 ft-lb	108 ± 14 N • m

\*\*For steel wheels and non-lubricated fasteners.

## Thread Cutting Screws (Zinc Plated Steel)

Type 1, Type 23, or Type F	
Thread Size	Baseline Torque*
No. 6 - 32 UNC	20 ± 5 in-lb
No. 8 - 32 UNC	30 ± 5 in-lb
No. 10 - 24 UNC	38 ± 7 in-lb
1/4 - 20 UNC	85 ± 15 in-lb
5/16 - 18 UNC	110 ± 20 in-lb
3/8 - 16 UNC	200 ± 100 in-lb

\*Hole size, material strength, material thickness and finish must be considered when determining specific torque values. All torque values are based on non-lubricated fasteners.

### Conversion Factors

$$\text{in-lb} \times 11.2985 = \text{N} \cdot \text{cm}$$

$$\text{ft-lb} \times 1.3558 = \text{N} \cdot \text{m}$$

$$\text{N} \cdot \text{cm} \times 0.08851 = \text{in-lb}$$

$$\text{N} \cdot \text{cm} \times 0.73776 = \text{ft-lb}$$

## Thread Cutting Screws (Zinc Plated Steel)

Threads Size	Threads per Inch		Baseline Torque*
	Type A	Type B	
No. 6	18	20	20 ± 5 in-lb
No. 8	15	18	30 ± 5 in-lb
No. 10	12	16	38 ± 7 in-lb
No. 12	11	14	85 ± 15 in-lb

\*Hole size, material strength, material thickness and finish must be considered when determining specific torque values. All torque values are based on non-lubricated fasteners.

# Equivalents and Conversions

## Decimal and Millimeter Equivalents

Fractions	Decimals	mm	Fractions	Decimals	mm
1/64	0.015625	0.397	33/64	0.515625	13.097
1/32	0.03125	0.794	16/32	0.53125	13.484
3/64	0.046875	1.191	35/64	0.546875	13.891
1/16	0.0625	1.588	9/16	0.5625	14.288
5/64	0.078125	1.984	37/64	0.578125	14.684
3/32	0.09375	2.381	19/32	0.59375	15.081
1/8	0.1250	3.175	5/8	0.6250	15.875
9/64	0.140625	3.572	41/64	0.640625	16.272
5/32	0.15625	3.969	21/32	0.65625	16.669
11/64	0.171875	4.366	43/64	0.671875	17.066
3/16	0.1875	4.762	11/64	0.6875	17.462
13/64	0.203125	5.159	45/64	0.703125	17.859
7/32	0.21875	5.556	23/32	0.71875	18.256
15/64	0.234375	5.953	47/64	0.734375	18.653
1/4	0.2500	6.350	3/4	0.7500	19.050
17/64	0.265625	6.747	49/64	0.765625	19.447
9/32	0.28125	7.144	25/32	0.78125	19.844
19/64	0.296875	7.541	51/64	0.796875	20.241
5/16	0.3125	7.541	13/16	0.8125	20.638
21/64	0.328125	8.334	53/64	0.828125	21.034
11/32	0.34375	8.731	27/32	0.84375	21.431
23/64	0.359375	9.128	55/64	0.859375	21.828
3/8	0.3750	9.525	7/8	0.8750	22.225
25/64	0.390625	9.922	57/64	0.890625	22.622
13/32	0.40625	10.319	29/32	0.90625	23.019
27/64	0.421875	10.716	59/64	0.921875	23.416
7/16	0.4375	11.112	15/16	0.9375	23.812
29/64	0.453125	11.509	61/64	0.953125	24.209
15/32	0.46875	11.906	31/32	0.96875	24.606
31/64	0.484375	12.303	63/64	0.984375	25.003
1/2	0.5000	12.700	1	1.000	25.400
<b>1 mm = 0.03937 in.</b>			<b>0.001 in. = 0.0254 mm</b>		

# U.S. to Metric Conversions

	To Convert	Into	Multiply By
<b>Linear Measurement</b>	Miles	Kilometers	1.609
	Yards	Meters	0.9144
	Feet	Meters	0.3048
	Feet	Centimeters	30.48
	Inches	Meters	0.0254
	Inches	Centimeters	2.54
	Inches	Millimeters	25.4
<b>Area</b>	Square Miles	Square Kilometers	2.59
	Square Feet	Square Meters	0.0929
	Square Inches	Square Centimeters	6.452
	Acre	Hectare	0.4047
<b>Volume</b>	Cubic Yards	Cubic Meters	0.7646
	Cubic Feet	Cubic Meters	0.02832
	Cubic Inches	Cubic Centimeters	16.39
<b>Weight</b>	Tons (Short)	Metric Tons	0.9078
	Pounds	Kilograms	0.4536
	Ounces	Grams	28.3495
<b>Pressure</b>	Pounds/Square Inch	Kilopascal	6.895
<b>Work</b>	Foot-Pounds	Newton-Meters	1.356
	Foot-Pounds	Kilogram-Meters	0.1383
	Inch-Pounds	Kilogram-Centimeters	1.152144
<b>Liquid Volume</b>	Quarts	Liters	0.9463
	Gallons	Liters	3.785
<b>Liquid Flows</b>	Gallons/Minute	Liters/Minute	3.785
<b>Temperature</b>	Fahrenheit	Celsius	1. Subtract by 32°
			2. Multiply by 5/9



## Table of Contents

General Troubleshooting ..... 3-3

## GEARS

The Systematic approach to defining, diagnosing and solving problems.



# G

### Gather Information

- Information reported by the customer
- Information observed by you
- Establish the what, where and when of the issue



# E

### Evaluate Potential Causes

- Consider possible causes of the problem to develop a hypothesis
- Narrow down the focus of the problem



# A

### Assess Performance

- Ensure you have all the necessary tools for testing
- Test all potential causes of the failure
- Reevaluate and create new hypotheses if necessary



# R

### Repair

- Return the unit to service by repairing, rebuilding or replacing



# S

### Solution Confirmation

- Did the issue go away
- Was the root cause of the issue correctly repaired
- Are there any other new symptoms

# General Troubleshooting

Problem	Possible Cause	Corrective Action
<b>The starter does not crank</b>	The blade control switch (PTO) is engaged.	Move the blade-control switch (PTO) to the disengaged position.
	The parking brake is not engaged.	Move the motion control levers to the neutral lock (park) position.
	The battery is dead.	Charge the battery.
	The electrical connections are corroded or loose.	Check the electrical connections for good contact.
	A switch is worn or damaged.	Test and replace faulty switch.
	The fuse is blown.	Replace the fuse.
<b>The engine does not start, starts hard, or fails to keep running</b>	The fuel tank is empty.	Fill the fuel tank.
	The throttle is not in the correct position.	Be sure that the throttle control is always in the fast positions.
	There is dirt in the fuel filter.	Replace the fuel filter.
	There is dirt, water, or stale fuel in the fuel system.	Clean and flush the fuel system.
	The air cleaner is dirty.	Clean or replace the air cleaner element.
	The seat switch is not functioning properly.	Check the seat switch and replace if faulty.
	The electrical connections are corroded, loose, or damaged.	Check the electrical connections for good contact. Clean the connector terminals thoroughly with the electrical contact cleaner and apply dielectric grease.
	The spark plug is fouled or improperly gapped.	Adjust or replace the spark plug.
	The spark plug wire is not connected.	Check the spark plug wire connection.
A switch is worn or damaged.	Test and replace faulty switch.	
<b>Engine loses power</b>	The engine load is excessive.	Reduce the ground speed or raise height-of-cut.
	The air cleaner is dirty.	Clean or replace the air cleaner element.
	The oil level in the crankcase is low.	Add oil to the crankcase.
	The cooling fins and air passages above the engine are plugged.	Remove the obstruction and thoroughly clean cooling fins and the air passages.
	The fuel tank vent system is plugged	Inspect the fuel tank vent system for obstruction and repair system.
	There is dirt in the fuel filter.	Replace the fuel filter.
	There is dirt, water, or stale fuel in the fuel system.	Clean and flush the fuel system.

# General Troubleshooting (continued)

Problem	Possible Cause	Corrective Action
<b>The engine overheats</b>	The engine load is excessive.	Reduce the ground speed or raise height-of-cut.
	The oil level in the crankcase is low.	Add oil to the crankcase.
	The cooling fins and the air passages above the engine are plugged.	Remove the obstruction and thoroughly clean cooling fins and the air passages.
<b>The mower pulls to the left or right (with levers fully forward)</b>	The tracking needs adjustment.	Adjust the tracking. View the Operator's Manual for the procedure.
	Smart speed shift forks are not both on the motion control linkage.	Remove the smart speed shift fork realign and install.
	The tire pressure in the drive tires is not correct.	Adjust the tire pressure in the drive tires.
<b>The machine does not drive</b>	The bypass rods are in the manual move position.	Place the bypass rods into the drive position.
	The drive belt is worn, loose, off a pulley, or broken.	Replace the drive belt.
	The tensioner spring is broken or missing.	Replace the spring.
	The hydraulic oil level is low in the transaxle.	Add hydraulic oil to the transaxle.
<b>The machine vibrates abnormally</b>	The cutting blade(s) is/are bent or unbalanced.	Install new cutting blade(s).
	The blade mounting bolt is loose.	Tighten the blade mounting bolt.
	The engine mounting bolts are loose.	Tighten the engine mounting bolts.
	The engine pulley, idler pulley, or blade pulley is loose.	Tighten the appropriate pulley, check to make sure idler springs are not over stretched.
	The engine pulley is damaged.	Replace the engine pulley.
	The blade spindle is bent.	Replace the spindle.
	The motor mount is loose or worn.	Check the mounting bolts.
<b>The machine produces an uneven cutting height</b>	The blade(s) are not sharp.	Sharpen the blade(s).
	The cutting blade(s) are bent.	Install new cutting blade(s).
	The mower deck is not level.	Level the mower deck from side-to-side and front-to-rear.
	The underside of mower is dirty.	Clean the underside of the mower.
	The tire pressure is not correct.	Adjust the tire pressure.
	The blade spindle is bent.	Replace the spindle.
<b>The blades do not rotate</b>	The mower deck belt is damaged, worn, loose, or broken.	Install a new deck belt.
	The mower deck belt is off the pulley.	Install the mower belt on the deck pulley and check the idler pulley, idler arm, and spring for correct position and function.
	The idler spring is broken or missing.	Replace the spring.



# General Troubleshooting (continued)

Problem	Possible Cause	Corrective Action
<b>The clutch does not engage</b>	There is a low voltage supply at the clutch.	Check the coil resistance, battery charge, charging system, and wiring connections and replace parts if necessary.
	The coil is damaged.	Replace the clutch.
	There is inadequate current supply.	Repair or replace the clutch lead wire or electrical system. Clean the connector contacts.
	The rotor/armature air gap is too large.	Replace the clutch.
	The blade control switch (PTO) is faulty.	Replace the blade control switch (PTO).





## Table of Contents

General Information .....	4-2
Service and Repairs .....	4-3
Engine Replacement.....	4-7
Muffler Replacement.....	4-19
Air Filter Cartridge Replacement.....	4-22


# General Information

The TIMECUTTER® series of mowers use 4 different engine combinations; 452cc Toro single cylinder OHV 4 cycle engine (LC1P92F-1), 708cc Toro twin cylinder OHV 4 cycle engine (LC2P77F), 726cc Kawasaki twin cylinder OHV 4 cycle engine (FR691V), and 725cc Kohler twin cylinder OHV 4 cycle engine (PS-KT735).

See the [Toro Twin Cylinder Engine Service Manual](#) for servicing the engine. All other engines, see the manufacturer's website.

# Service and Repairs


## Engine Assembly 1



g305684

**Figure 3**

- |                     |                   |
|---------------------|-------------------|
| 1. LC1P92F-1 Engine | 3. Exhaust Gasket |
| 2. Muffler          | 4. Oil Drain Tube |




g305686

Figure 4

- 1. 2P77F Engine
- 2. Muffler

- 3. Exhaust Gasket

## Engine Assembly 3




g305687

**Figure 5**

- |                    |                   |
|--------------------|-------------------|
| 1. Kawasaki Engine | 3. Oil Drain Tube |
| 2. Muffler         | 4. Heat Shield    |

## Engine Assembly 4



g305691

**Figure 6**

- 1. Kohler Engine
- 2. Muffler
- 3. Oil Drain Hose
- 4. Cable Tie





## Engine Removal (continued)

6. Disconnect the engine to chassis wiring harness.



g300617

**Figure 9**

- 
7. Remove the 10 mm nut securing the starter power wire to the starter.




g300618

**Figure 10**

- 
8. Remove 13 mm HH bolt securing the battery cable ground wire and the chassis harness ground wire to the engine block. Remove the ground wires from the engine block.

## Engine Removal (continued)



g300619

**Figure 11**

- 
9. Remove 10 (T-40) self-tapping screws securing the rear engine guard and muffler shield to the chassis. Remove the muffler shield and rear engine guard.



g300621

**Figure 12**

- 
10. Remove 8 mm HH bolt securing the throttle and choke cables to the throttle control plate. Remove the throttle and choke cables from the throttle control plate.


## Engine Removal (continued)



g300620

**Figure 13**

- 
11. Remove 4 (13 mm) nuts with lock washers securing the muffler to the engine. Remove the muffler from the engine.



g300622

**Figure 14**

- 
12. Remove the deck tensioner spring from the spring hook.

## Engine Removal (continued)



g300623

**Figure 15**

- 
13. Using an appropriate lifting device, raise the machine. Remove the deck belt from the clutch pulley.
  14. Disconnect the wiring to the clutch.



g300624

**Figure 16**

- 
15. Remove the 5/8 hex bolt securing the clutch to the crankshaft of the engine. Remove the clutch.

## Engine Removal (continued)



g300625

**Figure 17**

- 
16. Remove the hydro belt tensioner spring from the spring anchor point on the chassis.



g300671

**Figure 18**

- 
17. Relieve tension from the engine pulley. Slide the hydro belt off the engine pulley. Remove engine pulley from the crankshaft.
18. Remove the 4 hex bolts (9/16 inch) securing the engine to the chassis.

**Note:** Three of the bolts will have a flat washer, the 4th bolt going through the clutch anchor will not have a flat washer.

## Engine Removal (continued)



g300672

**Figure 19**

- 
19. Lower the machine to the ground. Remove the engine from the chassis.

## Engine Installation

1. Install the engine onto the chassis. Loosely install the 4 hex bolts (9/16 inch), 3 bolts have a flat washer the 4th bolt going through the clutch anchor does not have a flat washer.
2. Using an appropriate lifting device, raise the machine. Torque hex bolts to 45–56 N • m (400–500 in-lb).



g300672

**Figure 20**

- 
3. Install the engine pulley to the crankshaft. Slide the hydro belt onto the engine pulley. Add tension to the engine pulley.

## Engine Installation (continued)

4. Install the hydro belt tensioner spring to the spring anchor point on the chassis.



g300671

**Figure 21**



5. Install the clutch. Install the 5/8 hex bolt securing the clutch to the crankshaft of the engine. Torque bolt to 67.5–81 N • m (50–60 ft-lb).



g300625

**Figure 22**

6. Connect the wiring to the clutch.



## Engine Installation (continued)



g300624

**Figure 23**

7. Install the deck belt to the clutch pulley. Using an appropriate lifting device, lower the machine.
8. Install the deck tensioner spring to the spring hook.




g300623

**Figure 24**



9. Install the muffler to the engine. Secure with 4 (13 mm) nuts with lock washers. Torque nuts to 17–19 N • m (150–170 in-lb).

## Engine Installation (continued)



g300622

**Figure 25**

- 
10. Install the throttle and choke cables to the throttle control plate. Secure with 8 mm HH bolt securing the throttle and choke cables to the throttle control plate.



g300620

**Figure 26**



- 
11. Install the muffler shield and rear engine guard. Secure with 10 (T-40) self-tapping screws securing the rear engine guard and muffler shield to the chassis. Torque screws to 17–22.5 N • m (150–200 in-lb).

## Engine Installation (continued)




g300621

**Figure 27**



12. Install the ground wires to the engine block. Secure with 13 mm HH bolt securing the battery cable ground wire and the chassis harness ground wire to the engine block. Torque bolt to 22.5–25 N • m (200–225 in-lb).



g300619

**Figure 28**



## Engine Installation (continued)

13. Install the 10 mm nut securing the starter power wire to the starter. Torque nut to 10.5–11.5 N • m (96–105 in-lb).



g300618

**Figure 29**

- 
14. Connect the engine to chassis wiring harness.



g300617

**Figure 30**

- 
15. Install the fuel tank vent hose to the fuel tank vent orifice.

## Engine Installation (continued)



g300616

**Figure 31**

- 
16. Remove the clamp from the fuel hose. Install the fuel hose from the fuel filter. Using pliers, slide the hose clamp onto the fuel filter connection to the fuel hose.



g300615

**Figure 32**

- 
17. Add engine oil.
  18. Connect the positive battery cable first, then the negative battery cable to the battery.

## Muffler Replacement

### Muffler Removal

1. Park the machine on a level surface and set the parking brake. Stop the engine, wait for all moving parts to stop and remove the key.

## Muffler Removal (continued)


2. Disconnect the battery by removing the negative battery cable first, then the positive cable from the battery.
3. Remove 10 (T-40) self-tapping screws securing the rear engine guard and muffler shield to the chassis. Remove the muffler shield and rear engine guard.



g300621

**Figure 33**

- 
4. Remove 4 (13 mm) nuts with lock washers securing the muffler to the engine. Remove the muffler from the engine.



g300622

**Figure 34**


---

## Muffler Installation



## Muffler Installation (continued)

1. Install the muffler to the engine. Secure with 4 (13 mm) nuts with lock washers. Torque nuts to 17–19 N • m (150–170 in-lb).



g300622

Figure 35



2. Install the muffler shield and rear engine guard. Secure with 10 (T-40) self-tapping screws securing the rear engine guard and muffler shield to the chassis. Torque screws to 17–22.5 N • m (150–200 in-lb).



g300621

Figure 36

3. Connect the positive battery cable first, then the negative battery cable to the battery.

# Air Filter Cartridge Replacement

## Air Filter Cartridge Removal

1. Park the machine on a level surface and set the parking brake. Stop the engine, wait for all moving parts to stop and remove the key.
2. Lift the air cleaner cover door.



g300685

**Figure 37**

- 
3. Remove the air filter cartridge. Replace as necessary.



g300686

**Figure 38**

---

## Air Filter Cartridge Installation

1. Install the air filter cartridge onto the engine.



## Air Filter Cartridge Installation (continued)



g300686

**Figure 39**

- 
2. Lower the air cleaner cover door.



g300685

**Figure 40**





## Table of Contents


General Information .....	5-2
Service and Repairs .....	5-3
Caster Fork Replacement .....	5-15
Caster Wheel Bushing Replacement .....	5-17
Stub Shaft Replacement .....	5-18
Pod Replacement .....	5-22
Fuel Tank Replacement .....	5-25
Seat Assembly Replacement .....	5-28
MYRIDE® Seat/Platform Replacement .....	5-30
Steering Control Box Replacement .....	5-45
Motion Control Actuator Replacement .....	5-65
Smart Speed Assembly Replacement .....	5-74
Rear Engine Guard Replacement .....	5-85
Deck Lift Assembly 3 Point Replacement .....	5-86
Deck Lift Assembly 4 Point Replacement .....	5-95
Front Chassis Storage Box Replacement .....	5-99

# General Information

The TIMECUTTER® series uses a common frame. There are 2 different configurations of this frame a MYRIDE® suspension platform and a conventional solid platform. The frame is constructed from 10 gauge steel and now accommodates a relief in the rear crossmember for aid in easier drive belt replacement.

# Service and Repairs

## Chassis Assembly 1




g305797

**Figure 41**

- |             |                  |
|-------------|------------------|
| 1. Seat     | 3. Pivot Rod     |
| 2. Seat Pan | 4. Lanyard Cable |

## Chassis Assembly 2




g305817

**Figure 42**

- 1. Seat
- 2. Seat Pan
- 3. Pivot Rod
- 4. Lanyard Cable
- 5. Knob

## Chassis Assembly 3




g306183

**Figure 43**

- |                          |                          |
|--------------------------|--------------------------|
| 1. RH Handle Control     | 10. Retainer Plate       |
| 2. Control Arm           | 11. Speed Control Asm.   |
| 3. Non-Cavitating Damper | 12. LH Control Handle    |
| 4. Hydro Rod Pin         | 13. Eccentric            |
| 5. Actuator Arm Asm.     | 14. RH Control Plate Box |
| 6. RH Knob               | 15. Torsion Spring       |
| 7. LH Knob               | 16. LH Control Plate Box |
| 8. Front Hydro Rod       | 17. Storage Box          |
| 9. Rear Hydro Rod        | 18. Kick Plate           |

## Chassis Assembly 4




g306185

**Figure 44**

- |                             |                       |
|-----------------------------|-----------------------|
| 1. Ratcheting Fuel Cap      | 9. Fuel Hose          |
| 2. Throttle and Choke Cable | 10. Cable Tie         |
| 3. Control Panel            | 11. Orifice Adaptor   |
| 4. LH Pod                   | 12. Fuel Tank Asm.    |
| 5. RH Pod                   | 13. Grommet Bumper    |
| 6. RH Support Pod           | 14. LH Pod Support    |
| 7. Fuel Hose                | 15. Spring            |
| 8. Fuel Hose                | 16. Fuel Tank Support |



## Chassis Assembly 5




g306369

**Figure 45**

- |                        |                             |
|------------------------|-----------------------------|
| 1. Choke Cable         | 13. Fuel Hose               |
| 2. Throttle Cable      | 14. Orifice Adaptor         |
| 3. Control Panel       | 15. Fuel Hose               |
| 4. RH Support Pod      | 16. Carbon Canister         |
| 5. RH Pod              | 17. Carbon Canister Bracket |
| 6. Ratcheting Fuel Cap | 18. Carbon Canister Bracket |
| 7. LH Pod              | 19. Inline Fuel Filter      |
| 8. Tank Vent Hose      | 20. Fuel Hose               |
| 9. Fuel Hose           | 21. Spring                  |
| 10. Fuel Tank Asm.     | 22. Fuel Tank Support       |
| 11. Straight Fitting   | 23. Grommet Bumper          |
| 12. Fuel Hose          | 24. LH Pod Support          |

## Chassis Assembly 6




g306612

**Figure 46**

- |                                  |                               |
|----------------------------------|-------------------------------|
| 1. Seat Base Asm.                | 17. Seat Bumper               |
| 2. Lever Knob                    | 18. Cable Bracket             |
| 3. Adjustment Lever              | 19. Subframe                  |
| 4. Compression Spring            | 20. Lower Bracket             |
| 5. Extension Spring              | 21. Adjustment Rod            |
| 6. Cam Pulley                    | 22. Cotter Pin                |
| 7. Flange Bushing                | 23. Swing Arm                 |
| 8. Shock/Spring Asm.             | 24. RH Torsion Spring         |
| 9. Seat Bracket                  | 25. Spring Retainer           |
| 10. Seat Latch Bracket           | 26. Adjuster Plate            |
| 11. RH Upper Shock Bracket Mount | 27. Spring Retainer           |
| 12. LH Upper Shock Bracket Mount | 28. MYRIDE® Adjustment Cable  |
| 13. Seat Pan                     | 29. External Retaining Spring |
| 14. Clip                         | 30. LH Torsion Spring         |
| 15. Seat Stop Bracket            | 31. Spacer Tube               |
| 16. Seat Prop Rod                |                               |

## Chassis Assembly 7




g306653

**Figure 47**

- |                       |                               |
|-----------------------|-------------------------------|
| 1. Protector Cap      | 9. TIMECUTTER® Frame Weldment |
| 2. Compression Spring | 10. Hydro Plate Mount         |
| 3. Floor Pan          | 11. Footrest                  |
| 4. Cross Brace        | 12. Axle Stub Asm.            |
| 5. Seat Support       | 13. Grease Cap                |
| 6. Floor Pan          | 14. Right Front Hydro Mount   |
| 7. Hitch Bracket      | 15. Left Front Hydro Mount    |
| 8. Engine Guard       | 16. Muffler Guard             |

## Chassis Assembly 8




g306654

**Figure 48**

- |                               |                                |
|-------------------------------|--------------------------------|
| 1. Rail Guard                 | 9. Lower Cross Brace           |
| 2. RH Hydro Mount Plate       | 10. Axle Stub Asm.             |
| 3. Rubber Bumper              | 11. Grease Cap                 |
| 4. Hitch Bracket              | 12. Right Front Hydro Mount    |
| 5. Engine Guard               | 13. TIMECUTTER® Frame Weldment |
| 6. Footrest                   | 14. Left Front Hydro Mount     |
| 7. Seat Bumper                | 15. Hydro Mount Plate          |
| 8. Lower Damper Mount Bracket | 16. Muffler Guard              |


## Chassis Assembly 9



g306655

**Figure 49**

- |                         |                           |
|-------------------------|---------------------------|
| 1. Lever Grip           | 6. Decklift Pivot Bracket |
| 2. HOC Bracket          | 7. Deck Lift Asm.         |
| 3. Lift Lever           | 8. Pivot Pin              |
| 4. RH Arm Asm.          | 9. Deck Mount Rod         |
| 5. HOC Adjustment Plate | 10. LH Arm Asm.           |




g306690

Figure 50

- |                   |                         |
|-------------------|-------------------------|
| 1. HOC Bracket    | 8. Rear Pivot Asm.      |
| 2. HOC Link       | 9. Deck Lift Link       |
| 3. HOC Bracket    | 10. Deck Lift Gusset    |
| 4. HOC Pin        | 11. Flange Bearing      |
| 5. Foot Pedal     | 12. Shaft Cross Support |
| 6. Pan Mount      | 13. Front Pivot Asm.    |
| 7. Pivot Deck Pan |                         |


## Chassis Assembly 11



g306691

**Figure 51**

- |                            |                          |
|----------------------------|--------------------------|
| 1. Foot Lift Pedal         | 8. Deck Lift Asm.        |
| 2. Lever Grip              | 9. Lift Pedal            |
| 3. HOC Bracket             | 10. RH Arm Asm.          |
| 4. Foot Lift Pedal         | 11. HOC Adjustment Plate |
| 5. Link                    | 12. Pivot Pin            |
| 6. Lift Lever              | 13. Deck Mount Rod       |
| 7. Deck Lift Pivot Bracket | 14. LH Arm Asm.          |



g306775

Figure 52

- 1. Seal Guard
- 2. Wheel Spanner
- 3. Fork Asm.
- 4. Tire Asm.



# Caster Fork Replacement

## Caster Fork Removal

1. Park the machine on a level surface and set the parking brake. Stop the engine, wait for all moving parts to stop and remove the key.
2. Using an appropriate lifting device, raise the front of the machine off the floor.
3. Remove the  $\frac{3}{4}$  inch bolt and nut securing the wheel to the caster fork. Remove the wheel from the machine.



g300687

**Figure 53**

- 
4. Using a flat head screw driver, remove the top dust cover.



g308652

**Figure 54**

- 
5. Remove the  $\frac{1}{2}$  inch bolt securing the caster fork to stub shaft.
  6. Remove the caster fork from the stub shaft.

## Caster Fork Installation



1. Install the caster fork to the stub shaft.
2. Install the  $\frac{1}{2}$  inch bolt securing the caster fork to the stub shaft. Torque bolt to 22.5–25 N • m (200–225 in-lb).



g300689

**Figure 55**



3. Install the top dust cover.
4. Install the wheel to the machine. Secure with the  $\frac{3}{4}$  inch bolt and nut securing the wheel to the caster fork. Torque bolt and nut to 36.5–50 N • m (27–37 ft-lb).



g300687

**Figure 56**

5. Lower the front of the machine to the floor.

# Caster Wheel Bushing Replacement

## Caster Wheel Bushing Removal

1. Park the machine on a level surface and set the parking brake. Stop the engine, wait for all moving parts to stop and remove the key.
2. Using an appropriate lifting device, raise the front of the machine off the floor.
3. Remove the  $\frac{3}{4}$  inch bolt and nut securing the wheel to the caster fork. Remove the wheel from the machine.



g300687

**Figure 57**

- 
4. Remove the center axle from the bushings.



g300700

**Figure 58**

- 
5. Using a hammer and punch, remove the bushings from the wheel (2 bushings and 1 axle per wheel).
  6. Inspect bushings and axle, replace as necessary.

## Caster Wheel Bushing Installation

1. Install the bushings to the wheel (2 bushings and 1 axle per wheel).
2. Install the center axle to the bushings.



g300700

Figure 59



3. Install the wheel to the machine. Secure with a  $\frac{3}{4}$  inch bolt and nut securing the wheel to the caster fork. Torque bolt and nut to 36.5–50 N • m (27–37 ft-lb).



g300687

Figure 60

4. Lower the machine to the floor.

## Stub Shaft Replacement

### Stub Shaft Removal

1. Park the machine on a level surface and set the parking brake. Stop the engine, wait for all moving parts to stop and remove the key.

## Stub Shaft Removal (continued)

- Using an appropriate lifting device, raise the front of the machine off the floor.
- Remove the  $\frac{3}{4}$  inch bolt and nut securing the wheel to the caster fork. Remove the wheel from the machine.



g300687

**Figure 61**

- 
- Using a flat head screw driver, remove the top dust cover.




g300688

**Figure 62**

- 
- Remove the  $\frac{1}{2}$  inch bolt securing the caster fork to stub shaft. Remove the caster fork from the stub shaft.
  - Remove the 4 ( $\frac{9}{16}$  inch) nut and bolt (3 front, 1 back) securing the stub shaft to the front axle asm.

## Stub Shaft Removal (continued)



g300752

**Figure 63**

- 
7. Remove the stub shaft from the front axle asm.



g300753

**Figure 64**

- 
8. Remove the bearings from the stub shaft, inspect and replace as necessary.

## Stub Shaft Installation

1. Install the bearings to the stub shaft.
2. Install the stub shaft to the front axle asm.


## Stub Shaft Installation (continued)



g300753

**Figure 65**

3. Install the 4 (9/16 inch) nut and bolt (3 front, 1 back) securing the stub shaft to the front axle asm. Hand tighten all fasteners.



g300752

**Figure 66**

4. Lower the machine to the floor. The weight of the machine should be on the ground before tightening hardware.



5. Tighten the 2 bolts with nuts first, then tighten the self-tapping screws last (rear before front). Torque bolts with nuts and screws to 36.5–44.5 N • m (27–33 ft-lb).



6. Install the caster fork to the stub shaft. Secure with ½ inch bolt securing the caster fork to the stub shaft. Torque the bolt to 36.5–44.5 N • m (27–33 ft-lb).
7. Install the dust cover.

## Stub Shaft Installation (continued)



g300688

Figure 67



8. Install the wheel to the machine. Secure with the  $\frac{3}{4}$  inch bolt and nut securing the wheel to the caster fork. Torque the bolt to 36.5–50 N • m (27–37 ft-lb).



g300687

Figure 68

## Pod Replacement

### Pod Removal

1. Park the machine on a level surface and set the parking brake. Stop the engine, wait for all moving parts to stop and remove the key.
2. Flip the seat forward.
3. Using a T-30 torque bit, remove the 3 screws securing the pod to the pod support brackets. Repeat for opposite side.



## Pod Removal (continued)

4. Remove the fuel cap on the LH side pod.
5. Move the motion control from the neutral lock to the neutral position.
6. Remove the LH pod from the machine.

**Note:** The LH and RH pod removal are the same except the RH pod has the control panel and smart speed knob.

7. Using Philips head screw driver, remove the screw securing the smart speed knob to the smart speed lever. Remove the smart speed knob from the smart speed lever.



g301691

**Figure 69**

- 
8. Using a Philips head screw driver, remove the screw securing the control panel to the RH pod. Move the control panel to the side.



g301692

**Figure 70**

- 
9. Remove the RH pod from the machine.

## Pod Installation

1. Place the RH pod into position on the machine.
2. Install the control panel. Hand tighten with the screw securing the control panel to the RH pod.



g301692

**Figure 71**

3. Install the smart speed knob to the smart speed lever. Hand tighten with the screw securing the smart speed knob to the smart speed lever.



g301691

**Figure 72**

4. Place the LH pod into position on the machine.
5. Move the motion control from the neutral position to the neutral lock position.
6. Install the fuel cap on the LH side pod.
7. Install the 3 screws (per pod) securing the pod to the pod support brackets. Torque screws to 11 N • m (100 in-lb).
8. Flip the seat back into position.



# Fuel Tank Replacement

## Fuel Tank Removal

1. Park the machine on a level surface and set the parking brake. Stop the engine, wait for all moving parts to stop and remove the key.
2. Flip the seat forward.
3. Using a T-30 torque bit, remove the 3 screws (per pod) securing the pod to the pod support brackets.
4. Remove the fuel cap on the LH side pod.
5. Move the motion control from the neutral lock to the neutral position.
6. Remove the LH pod from the machine.
7. Install the fuel cap to the LH pod to prevent fuel spill. Fully tighten.



g301703

**Figure 73**

- 
8. Remove the spring clamps securing the fuel hose and the fuel vent hose. Remove the fuel hose and fuel vent hose from the fuel tank fittings. Cap all hoses.

**Note:** The fuel tank labels both vent and fuel ports and line orientation.

## Fuel Tank Removal (continued)



g301704

**Figure 74**

- 
9. Remove the 2 strap fasteners from the bottom of the fuel tank. Remove the fuel tank from the chassis.



g301705

**Figure 75**

---

## Fuel Tank Installation

1. Install the fuel tank to the chassis. Secure with the 2 strap fasteners at the bottom of the fuel tank.

## Fuel Tank Installation (continued)



g301705

**Figure 76**

2. Remove the cap from the hoses. Install the fuel hose and fuel vent hose to the fuel tank fittings. Secure with spring clamps.

**Note:** The fuel hose and fuel vent hose ports and hose orientation are labeled on the fuel tank.



g301704

**Figure 77**

3. Remove the fuel cap from the LH pod.
4. Install the LH pod into position on the machine.
5. Move the motion control from the neutral position to the neutral lock.
6. Install the fuel cap on the LH side pod.
7. Install the 3 screws (per pod) securing the pod to the pod support brackets. Torque screws to 11 N • m (100 in-lb).



## Fuel Tank Installation (continued)

8. Flip the seat back into position.

## Seat Assembly Replacement

### Seat Assembly Removal

1. Park the machine on a level surface and set the parking brake. Stop the engine, wait for all moving parts to stop and remove the key.
2. Flip the seat forward and remove the seat switch connection.



g301716

**Figure 78**

- 
3. Flip the seat back to the operator position.
  4. Remove the 2 (T-27) screws from the front of the seat pan.




g301717

**Figure 79**

- 
5. Lift and remove the seat from the seat rod.

## Seat Assembly Removal (continued)




g301718

**Figure 80**

---

## Seat Assembly Installation

1. Install the seat onto the seat rod.



g301718

**Figure 81**



## Seat Assembly Installation (continued)

2. Install the 2 (T-27) screws to the front of the seat pan. Torque screws to 11 N • m (100 in-lb).



g301717

Figure 82

- 
3. Install the seat switch connection.



g301716

Figure 83

- 
4. Flip the seat back into the operator position.

## MYRIDE® Seat/Platform Replacement


### MYRIDE® Seat/Platform Removal

1. Park the machine on a level surface and set the parking brake. Stop the engine, wait for all moving parts to stop and remove the key.



## MYRIDE® Seat/Platform Removal (continued)

2. Disconnect the battery by removing the negative battery cable first, then the positive cable from the battery.
3. Lift the seat forward.
4. Disconnect the seat switch.
5. Remove the 3/8 inch head bolt securing the seat stop bracket to the seat mount. Remove the seat stop bracket from the machine.
6. Lower the seat. Slide the seat to the most forward position.
7. Remove the seat from the machine.



g301739

Figure 84

- 
8. Remove the 2 (1/2 inch) bolts securing the seat mount to the MYRIDE® platform.




g301740

Figure 85

- 
9. Remove the seat mount from the machine.

## MYRIDE® Seat/Platform Removal (continued)



g301741

**Figure 86**

10. Using a T-30 torque bit, remove the 3 screws securing the pod to the pod support brackets. Repeat for opposite side.
11. Move the motion control from the neutral lock to the neutral position.
12. Using a Philips head screw driver, remove the screw securing the smart speed knob to the smart speed lever. Remove the smart speed knob from the smart speed lever.



g301691

**Figure 87**

13. Using a Philips head screw driver, remove the screw securing the control panel to the RH pod. Move the control panel to the side.

## MYRIDE® Seat/Platform Removal (continued)



g301692

Figure 88

14. Remove the RH pod from the machine.
15. Move the MYRIDE® adjustment lever to most forward position. Relieve the tension from the MYRIDE® adjustment spring cable.



g301755

Figure 89

16. Remove the MYRIDE® assist spring from the MYRIDE® cam assembly and the frame.  
**Note:** Long end secures towards the front of the machine.
17. Move the MYRIDE® adjustment lever to the most rearward position. Using a ½ inch wrench, remove the front nut from the MYRIDE® cable. Remove the MYRIDE® cable from the cam assembly.
18. Unscrew the knob. Remove the ½ inch bolt and 9/16 inch nut securing the cam to the chassis.

## MYRIDE® Seat/Platform Removal (continued)

19. Remove the cable from the cam.



g301756

**Figure 90**

---

20. Remove the cam assembly from the machine.



g309644

**Figure 91**



**CAUTION**



**May need assistance to perform next step.**

---

21. Remove the nut securing the top of the front MYRIDE® shock to the MYRIDE® platform.


## MYRIDE® Seat/Platform Removal (continued)



g301752

**Figure 92**


- 
22. Using a ratchet strap, hook the strap to both frame rails on either side of the MYRIDE® platform.



g301753

**Figure 93**

## MYRIDE® Seat/Platform Removal (continued)



g301754

Figure 94



### CAUTION



**May need assistance to perform next step. Springs are under extreme load.**

23. Remove the 2 (1/2 inch) bolts and nuts securing the MYRIDE® stop bracket to the MYRIDE® platform.



g301769

Figure 95

24. Relieve the tension from the MYRIDE® platform by removing the ratchet strap.
25. Remove the 2 (9/16) inch nuts and bolts securing the MYRIDE® trailing to the chassis.


## MYRIDE® Seat/Platform Removal (continued)



g301770

**Figure 96**

- 
26. Using an appropriate lifting device, remove the MYRIDE® platform from the machine.



g301771


**Figure 97**

---

## MYRIDE® Seat/Platform Installation

1. Using an appropriate lifting device, install the MYRIDE® platform onto the machine.

## MYRIDE® Seat/Platform Installation (continued)



g301771

Figure 98



### CAUTION



**May need assistance to perform next step. Springs are under extreme load.**



2. Install the 2 (9/16 inch) inch nuts and bolts securing the MYRIDE® trailing to the chassis. Torque nuts and bolts to 40.5–44.5 N • m (30–33 ft-lb).



g301770

Figure 99



3. Install the 2 (1/2 inch) bolts and nuts securing the MYRIDE® stop bracket to the MYRIDE® platform. Torque the bolts and nuts to 22.5–25 N • m (200–225 in-lb).



## MYRIDE® Seat/Platform Installation (continued)



g301769

**Figure 100**


- 
- Using a ratchet strap, hook the strap to both frame rails on either side of the MYRIDE® platform.



g301754

**Figure 101**

## MYRIDE® Seat/Platform Installation (continued)



g301753

Figure 102



### CAUTION



**May need assistance to perform next step.**

5. Push on the rear of the MYRIDE® platform and use the ratchet strap to compress and secure the torsion springs on the MYRIDE® platform.
6. Install the nut securing the top of the front MYRIDE® shock to the MYRIDE® platform. Torque nut to 40.5–44.5 N • m (30–33 ft-lb).
7. Install the cam assembly onto the machine.
8. Install the cable to the cam.



g301756

Figure 103

## MYRIDE® Seat/Platform Installation (continued)



9. Screw on the knob until hand tight. Install the ½ inch bolt and 9/16 inch nut securing the cam to the chassis. Torque bolt and nut to 40.5–44.5 N • m (30–33 ft-lb).
10. Install the MYRIDE® cable to the cam assembly. Move the MYRIDE® adjustment lever to the most forward position. Using a ½ inch wrench, install the front nut to the MYRIDE® cable.



g301755

**Figure 104**

- 
11. Install the MYRIDE® assist spring to the MYRIDE® cam assembly and the frame.  
**Note:** The long end secures towards the front of the machine.
  12. Add tension to the MYRIDE® adjustment spring cable. Move the MYRIDE® adjustment lever to most rearward position.
  13. Place the RH pod into position on the machine.
  14. Install the control panel. Hand tighten the screw securing the control panel to the RH pod.

## MYRIDE® Seat/Platform Installation (continued)



g301692

**Figure 105**

- 
15. Install the smart speed knob to the smart speed lever. Hand tighten the screw securing the smart speed knob to the smart speed lever.



g301691

**Figure 106**


- 
16. Move the motion control from the neutral position to the neutral lock position.



17. Install the 3 screws (per pod) securing the pod to the pod support brackets. Torque screws to 11 N • m (100 in-lb).

18. Install the seat mount to the machine.

## MYRIDE® Seat/Platform Installation (continued)



g301741

**Figure 107**



19. Install the 2 (1/2 inch) bolts securing the seat mount to the MYRIDE® platform. Torque bolts to 5.5–6.5 N • m (53–60 in-lb).




g301740

**Figure 108**

20. Install the seat onto the machine.

## MYRIDE® Seat/Platform Installation (continued)



g301739

**Figure 109**

---

21. Slide the seat to most rearward position. Lower the seat.



22. Install the seat stop bracket to the machine. Install the 3/8 inch head bolt securing the seat stop bracket to the seat mount. Torque head bolt to 11 N • m (100 in-lb).



g301774

**Figure 110**

---

23. Connect the seat switch.

## MYRIDE® Seat/Platform Installation (continued)



g301773

**Figure 111**

- 
24. Lower the seat forward.
  25. Connect the positive battery cable first, then the negative battery cable to the battery.

## Steering Control Box Replacement

### Steering Control Box Removal

1. Park the machine on a level surface and set the parking brake. Stop the engine, wait for all moving parts to stop and remove the key.
2. To relieve tension on deck lift handle, place wood blocks (2x4 inches) under each side of the deck. Lower the deck until tension is relieved from the lift handle.
3. Flip the seat forward and remove the seat switch connection.

## Steering Control Box Removal (continued)



g301716

**Figure 112**

- 
4. Flip the seat back to the operator position.
  5. Remove the 2 (T-27) screws from the front of the seat pan.




g301717

**Figure 113**

- 
6. Lift and remove the seat from the seat rod.



## Steering Control Box Removal (continued)



g301718

**Figure 114**

7. Using a T-30 torque bit, remove the 3 screws securing the pod to the pod support brackets. Repeat for opposite side.
8. Remove the fuel cap on the LH side pod.
9. Move the motion control from the neutral lock to the neutral position.
10. Remove the LH pod from the machine.

**Note:** LH and RH pod removal are the same except the RH pod has the control panel and smart speed knob.

11. Reinstall the fuel cap to the LH pod to prevent fuel spill. Fully tighten.



g301703

**Figure 115**

12. Using Philips head screw driver, remove the screw securing the smart speed knob to the smart speed lever. Remove the smart speed knob from the smart speed lever.

## Steering Control Box Removal (continued)



g301691

Figure 116

- 
- Using a Philips head screw driver, remove the screw securing the control panel to the RH pod. Move the control panel to the side.



g301692

Figure 117

- 
- Remove the RH pod from the machine.
  - Remove the spring clamps securing the fuel hose and the fuel vent hose. Remove the fuel hose and fuel vent hose from the fuel tank fittings. Cap all hoses.

**Note:** The fuel tank labels both vent and fuel ports and line orientation.

## Steering Control Box Removal (continued)



g301704

**Figure 118**

- 
16. Remove the 2 strap fasteners from the bottom of the fuel tank. Remove the fuel tank from the chassis.




g301705

**Figure 119**

- 
17. Remove the 2 front pod mounting screws (T-30).  
18. Remove the 2 screws (T-20) securing the cubbie to the chassis.

## Steering Control Box Removal (continued)



g301788

**Figure 120**

- 
19. Move the smart speed selector to the turtle/trim position.
  20. Remove the cubbie by lifting the front of each pod to maneuver the cubbie away from the chassis.
  21. Remove the 2 (9/16 inch) bolts per motion control arm.



g301789

**Figure 121**

- 
22. Remove the top T-30 screw and 7/16 inch nut securing the damper to the chassis and motion control actuator.

## Steering Control Box Removal (continued)



g301790

**Figure 122**

- 
23. Remove the motion control neutral switch from the steering control box by depressing the tabs on either side of the switch. Remove the switch from the control box.



g301791

**Figure 123**


## Steering Control Box Removal (continued)



g301792

**Figure 124**

- 
24. Remove the 5/16 inch screw (1 per mount) securing the 2 speed selector rod retaining mounts.



g301793

**Figure 125**

- 
25. Pull back on the speed selector rod lift and remove the speed selector rod from the machine.

## Steering Control Box Removal (continued)



g301896

**Figure 126**

- 
26. Remove the 7/16 inch nut securing the motion control rod to the motion control actuator. Remove the motion control rod.



g301897

**Figure 127**

- 
27. Remove the 4 (T-30) screws (4 per control box) securing the steering control box to the chassis. Remove the steering control box and seat rod from the machine.

**Note:** When removing the RH steering control box, remove the T-30 screw securing the height-of-cut bracket to the chassis.

## Steering Control Box Removal (continued)



g301898

**Figure 128**

---

## Steering Control Box Disassembly

1. Remove the T-30 screw securing the return to neutral from reverse spring to the steering control box. Remove the return to neutral from reverse spring.



g301930

**Figure 129**

2. Remove the 9/16 inch nut and 3/4 inch bolt securing the actuator arm to the steering control box. Remove the actuator arm from the steering control box.



## Steering Control Box Disassembly (continued)



g301931

**Figure 130**

- 
3. Remove the 9/16 inch nut and bolt securing the lower motion control lever to the motion control actuator.



g301932

**Figure 131**

- 
4. Remove the 7/16 inch nut and bolt securing the tracking adjustment block to the steering control box.

## Steering Control Box Disassembly (continued)



g301933

**Figure 132**

## Steering Control Box Assembly



1. Install the 7/16 inch nut and bolt securing the tracking adjustment block to the steering control box. Torque nut and bolt to 11 N • m (100 in-lb).



g301932

**Figure 133**



2. Install the 9/16 inch nut and bolt securing the lower motion control lever to the motion control actuator. Torque nut and bolt to 40.5–44.5 N • m (30–33 ft-lb).



3. Install the actuator arm in the steering control box. Install the 9/16 inch nut and 3/4 inch bolt securing the actuator arm to the steering control box. Torque nut and bolt to 40.5–44.5 N • m (30–33 ft-lb).

## Steering Control Box Assembly (continued)



g301931

Figure 134



4. Install the return to neutral to the reverse spring. Install the T-30 screw securing the return to neutral from reverse spring to the steering control box. Torque screw to 11 N • m (100 in-lb).



g301930

Figure 135

## Steering Control Box Installation



1. Install the steering control box and seat rod to the machine. Install the 4 (number 30 torque) screws (4 per control box) securing the steering control box to the chassis. Torque screws to 17–22.5 N • m (150–200 in-lb).

**Note:** When installing the RH steering control box, install the T-30 screw securing the height-of-cut bracket chassis.

## Steering Control Box Installation (continued)



g301898

**Figure 136**



2. Install the motion control rod. Install the 7/16 inch nut securing the motion control rod to the motion control actuator. Torque nut to 11 N • m (100 in-lb).



g301897

**Figure 137**

3. Install the speed selector rod to the machine.

## Steering Control Box Installation (continued)




g301896

**Figure 138**



4. Install the 5/16 inch screw (1 per mount) securing the 2 speed selector rod retaining mounts. Torque screw to 4.5–5 N • m (42–47 in-lb).



g301793

**Figure 139**

5. Install the switch into the control box by depressing the tabs on either side of the switch.

## Steering Control Box Installation (continued)



g301791

**Figure 140**



6. Install the top T-30 screw and 7/16 inch nut securing the damper to the chassis and motion control actuator. Torque screw and nut to 11 N • m (100 in-lb).



g301790

**Figure 141**



7. Install the 2 (9/16 inch) bolts per motion control arm. Torque bolts to 40.5–44.5 N • m (30–33 ft-lb).


## Steering Control Box Installation (continued)



g301789

**Figure 142**

- 
8. Install the cubbie onto the machine.
  9. Move the smart speed selector to the trim/turtle position.
  10. Install the 2 screws (T-20) securing the cubbie to the chassis. Torque screws to 11 N • m (100 in-lb).



g301788

**Figure 143**

- 
11. Install the fuel tank to the chassis. Secure with the 2 strap fasteners at the bottom of the fuel tank.

## Steering Control Box Installation (continued)



g301705

**Figure 144**



12. Install the 2 front pod mounting screws (T-30). Torque screws to 11 N • m (100 in-lb).
13. Remove the cap from the hoses. Install the fuel hose and fuel vent hose to the fuel tank fittings. Secure with spring clamps.

**Note:** The fuel hose and fuel vent hose ports and hose orientation are labeled on the fuel tank.



g301704

**Figure 145**

14. Place the RH pod into position on the machine.
15. Install the control panel. Hand tighten with the screw securing the control panel to the RH pod.



## Steering Control Box Installation (continued)



g301692

**Figure 146**

- 
16. Install the smart speed knob to the smart speed lever. Hand tighten with the screw securing the smart speed knob to the smart speed lever.




g301691

**Figure 147**

- 
17. Place the LH pod into position on the machine.
  18. Move the motion control from the neutral position to the neutral lock position.
  19. Install the fuel cap on the LH side pod.
  20. Install the 3 screws (per pod) securing the pod to the pod support brackets. Torque screws to 11 N • m (100 in-lb).
  21. Flip the seat back into position.
  22. Install the seat onto the seat rod.



## Steering Control Box Installation (continued)



g301718

**Figure 148**



23. Install the 2 (T-27) screws to the front of the seat pan. Torque screws to 11 N • m (100 in-lb).



g301717

**Figure 149**

24. Install the seat switch connection.

## Steering Control Box Installation (continued)



g301716

**Figure 150**

- 
25. Flip the seat back into the operator position.

## Motion Control Actuator Replacement

### Motion Control Actuator Removal

1. Park the machine on a level surface and set the parking brake. Stop the engine, wait for all moving parts to stop and remove the key.
2. To relieve tension on deck lift handle, place wood blocks (2x4 inches) under each side of the deck. Lower the deck until tension is relieved from the lift handle.
3. Flip the seat forward and remove the seat switch connection.



g301716

**Figure 151**

- 
4. Flip the seat back to the operator position.

## Motion Control Actuator Removal (continued)


5. Remove the 2 (T-27) screws from the front of the seat pan.



g301717

**Figure 152**

- 
6. Lift and remove the seat from the seat rod.



g301718

**Figure 153**

- 
7. Using T-30 torque bit, remove the 3 screws securing the pod to the pod support brackets. Repeat for opposite side.
  8. Remove the fuel cap on the LH side pod.
  9. Move the motion control from the neutral lock to the neutral position.
  10. Remove the LH pod from the machine.

**Note:** The LH and RH pod removal are the same except the RH pod has the control panel and smart speed knob.

11. Reinstall the fuel cap to the LH pod to prevent fuel spill. Fully tighten.

## Motion Control Actuator Removal (continued)



g301703

**Figure 154**

- 
- Using Philips head screw driver, remove the screw securing the smart speed knob to the smart speed lever. Remove the smart speed knob from the smart speed lever.



g301691

**Figure 155**

- 
- Using a Philips head screw driver, remove the screw securing the control panel to the RH pod. Move the control panel to the side.

## Motion Control Actuator Removal (continued)



g301692

**Figure 156**

- 
14. Remove the RH pod from the machine.
  15. Remove the spring clamps securing the fuel hose and the fuel vent hose. Remove the fuel hose and fuel vent hose from the fuel tank fittings. Cap all hoses.

**Note:** The fuel tank labels both vent and fuel ports and line orientation.



g301704

**Figure 157**

- 
16. Remove the 2 strap fasteners from the bottom of the fuel tank. Remove the fuel tank from the chassis.


## Motion Control Actuator Removal (continued)



g301705

**Figure 158**

- 
17. Remove the 2 front pod mounting screws (T-30).
  18. Remove the 2 screws (T-20) securing the cubbie to the chassis.



g301788

**Figure 159**

- 
19. Move the smart speed selector to the trim/turtle position.
  20. Remove the cubbie by lifting the front of each pod to maneuver the cubbie away from the chassis.
  21. Remove the 2 (9/16 inch) bolts per motion control arm.
  22. Remove the top T-30 screw and 7/16 inch nut securing the damper to the chassis and motion control actuator.
  23. Disconnect the motion control neutral switch from the steering control box by depressing the tabs on either side of the switch. Disconnect the switch from the connector.
  24. Remove the motion control actuator from the machine.

## Motion Control Actuator Installation

1. Install the motion control actuator onto the machine.
2. Connect the switch to the connector. Install the motion control neutral switch into the steering control box by depressing the tabs on either side of the switch.



3. Install the top T-30 screw and 7/16 inch nut securing the damper to the chassis and motion control actuator. Torque screw and nut to 11 N • m (100 in-lb).



4. Install the 2 (9/16 inch) bolts per motion control arm. Torque bolt to 40.5–44.5 N • m (30–33 ft-lb).

5. Install the cubbie by lifting the front of each pod to maneuver the cubbie onto the chassis.

6. Move the smart speed selector to the trim/turtle position.



7. Install the 2 screws (T-20) securing the cubbie to the chassis. Torque screws to 11 N • m (100 in-lb).



8. Install the 2 (T-30) front pod mounting screws. Torque the screws to 11 N • m (100 in-lb).

9. Install the fuel tank to the chassis. Install the 2 strap fasteners to the bottom of the fuel tank.



g301705

Figure 160

10. Uncap the hoses. Install the fuel hose and fuel vent hose to the fuel tank fittings. Install the spring clamps securing the fuel hose and the fuel vent hose.

**Note:** The fuel tank labels both vent and fuel ports and line orientation.



## Motion Control Actuator Installation (continued)



g301704

**Figure 161**

11. Install the RH pod to the machine.
12. Move the control panel into position on the machine. Using a Philips head screw driver, hand tighten the screw securing the control panel to the RH pod.



g301692

**Figure 162**

13. Install the smart speed knob to the smart speed lever. Using a Philips head screw driver, hand tighten the screw securing the smart speed knob to the smart speed lever.

## Motion Control Actuator Installation (continued)



g301691

Figure 163

- 
14. Reinstall the fuel cap to the LH pod to prevent fuel spill. Fully tighten.



g301703


Figure 164

- 
15. Install the LH pod to the machine.

**Note:** The LH and RH pod install are the same except the RH pod has the control panel and smart speed knob.

16. Move the motion control from the neutral lock to the neutral position.
17. Remove the fuel cap on the LH side pod.
18. Using a T-30 torque bit, install the 3 screws securing the pod to the pod support brackets. Repeat for opposite side.
19. Lift and install the seat to the seat rod.

## Motion Control Actuator Installation (continued)



g301718

**Figure 165**



20. Install the 2 (T-27) screws to the front of the seat pan. Torque screw to 11 N • m (100 in-lb).



g301717

**Figure 166**

21. Flip the seat forward.
22. Install the seat switch connection and flip the seat into the operator's position.
23. Raise the deck until tension is added to the lift handle. Remove the wood blocks (2x4 inches) under each side of the deck.

# Smart Speed Assembly Replacement

## Smart Speed Assembly Removal

1. Park the machine on a level surface and set the parking brake. Stop the engine, wait for all moving parts to stop and remove the key.
2. To relieve tension on deck lift handle, place wood blocks (2x4 inches) under each side of the deck. Lower the deck until tension is relieved from the lift handle.
3. Flip the seat forward and remove the seat switch connection.



g301716

**Figure 167**

- 
4. Flip the seat back to the operator position.
  5. Remove the 2 (T-27) screws from the front of the seat pan.




g301717

**Figure 168**

- 
6. Lift and remove the seat from the seat rod.

## Smart Speed Assembly Removal (continued)



g301718

**Figure 169**

7. Using a T-30 torque bit, remove the 3 screws securing the pod to the pod support brackets. Repeat for opposite side.
8. Remove the fuel cap on the LH side pod.
9. Move the motion control from the neutral lock to the neutral position.
10. Remove the LH pod from the machine.

**Note:** The LH and RH pod removal are the same except the RH pod has the control panel and smart speed knob.

11. Reinstall the fuel cap to the LH pod to prevent fuel spill. Fully tighten.



g301703

**Figure 170**

12. Using Philips head screw driver, remove the screw securing the smart speed knob to the smart speed lever. Remove the smart speed knob from the smart speed lever.

## Smart Speed Assembly Removal (continued)



g301691

Figure 171

- 
- Using a Philips head screw driver, remove the screw securing the control panel to the RH pod. Move the control panel to the side.



g301692

Figure 172

- 
- Remove the RH pod from the machine.
  - Remove the spring clamps securing the fuel hose and the fuel vent hose. Remove the fuel hose and fuel vent hose from the fuel tank fittings. Cap all hoses.

**Note:** The fuel tank labels both vent and fuel ports and line orientation.

## Smart Speed Assembly Removal (continued)



g301704

**Figure 173**

- 
16. Remove the 2 strap fasteners from the bottom of the fuel tank. Remove the fuel tank from the chassis.




g301705

**Figure 174**

- 
17. Remove the 2 screws (T-20) securing the cubbie to the chassis.

## Smart Speed Assembly Removal (continued)



g301788

**Figure 175**

18. Move the smart speed selector to the turtle/trim position.
19. Remove the cubbie by lifting the front of each pod to maneuver the cubbie away from the chassis.
20. Remove the 2 (9/16 inch) bolts per motion control arm.
21. Remove the top T-30 screw and 7/16 inch nut securing the damper to the chassis and motion control actuator.
22. Disconnect the motion control neutral connector from the steering control box by depressing the tabs on either side of the switch. Disconnect the switch from the connector.
23. Remove the 5/16 inch screw (1 per mount) securing the 2 speed selector rod retaining mounts.
24. Pull back on the speed selector rod lift and remove the speed selector rod from the machine.

## Smart Speed Assembly Installation

1. Install the speed selector rod onto the machine.



## Smart Speed Assembly Installation (continued)



g309648

**Figure 176**



2. Install the 5/16 inch screw (1 per mount) securing the 2 speed selector rod retaining mounts. Torque screw to 4.5–5 N • m (42–47 in-lb).



g309649

**Figure 177**

3. Connect the switch to the connector. Connect the motion control neutral connector to the steering control box by depressing the tabs on either side of the switch.

## Smart Speed Assembly Installation (continued)



g309652

Figure 178



4. Install the top T-30 screw and 7/16 inch nut securing the damper to the chassis and motion control actuator. Torque screw and nut to 11 N • m (100 in-lb).




5. Install the 2 (9/16 inch) bolts per motion control arm. Torque bolts to 40.5–44.5 N • m (30–33 ft-lb).
6. Install the cubbie by lifting the front of each pod to maneuver the cubbie onto the chassis.
7. Move the smart speed selector to the trim/turtle position.



8. Install the 2 screws (T-20) securing the cubbie to the chassis. Torque screws to 11 N • m (100 in-lb).

## Smart Speed Assembly Installation (continued)



g301788

**Figure 179**



9. Install the 2 (T-30) front pod mounting screws. Torque screws to 11 N • m (100 in-lb).
10. Install the fuel tank to the chassis. Install the 2 strap fasteners to the bottom of the fuel tank.



g301705

**Figure 180**

11. Uncap the hoses. Install the fuel hose and fuel vent hose to the fuel tank fittings. Install the spring clamps securing the fuel hose and the fuel vent hose.

**Note:** The fuel tank labels both vent and fuel ports and line orientation.

## Smart Speed Assembly Installation (continued)



g301704

**Figure 181**

- 
12. Install the RH pod to the machine.
  13. Place the control panel into position on the machine. Using a Philips head screw driver, hand tighten the screw securing the control panel to the RH pod.



g301692

**Figure 182**

- 
14. Install the smart speed knob to the smart speed lever. Using Philips head screw driver, hand tighten the screw securing the smart speed knob to the smart speed lever.

## Smart Speed Assembly Installation (continued)



g301691

**Figure 183**

15. Remove the fuel cap from the fuel tank.

16. Install the LH pod to the machine.

**Note:** The LH and RH pod install are the same except the RH pod has the control panel and smart speed knob.


17. Move the motion control from the neutral lock to the neutral position.



18. Using a T-30 torque bit, install the 3 screws securing the pod to the pod support brackets. Repeat for opposite side. Torque screws to 11 N • m (100 in-lb).

19. Install the fuel cap on the LH side pod.

20. Lift and install the seat to the seat rod.



g301718

**Figure 184**

## Smart Speed Assembly Installation (continued)



21. Install the 2 (T-27) screws to the front of the seat pan. Torque screws to 11 N • m (100 in-lb).



g301717

**Figure 185**

- 
22. Flip the seat back to the operator position.
  23. Flip the seat forward and install the seat switch connection.



g301716

**Figure 186**

- 
24. Raise the deck until tension is added to the lift handle. Remove the wood blocks (2x4 inches) under each side of the deck.

# Rear Engine Guard Replacement

## Rear Engine Guard Removal

1. Park the machine on a level surface and set the parking brake. Stop the engine, wait for all moving parts to stop and remove the key.
2. Disconnect the battery by removing the negative battery cable first, then the positive cable.
3. Remove 10 (T-40) self-tapping screws securing the rear engine guard and muffler shield to the chassis. Remove the muffler shield and rear engine guard.



g300621

**Figure 187**

- 
4. Remove the rear engine guard.

## Rear Engine Guard Installation



1. Install the rear engine guard.
2. Install the muffler shield and rear engine guard. Install 10 (T-40) self-tapping screws securing the rear engine guard and muffler shield to the chassis. Torque screws to 17–22.5 N • m (150–200 in-lb).

## Rear Engine Guard Installation (continued)



g300621

**Figure 188**

- 
3. Connect the battery by installing the positive battery cable first, then the negative battery cable.

## Deck Lift Assembly 3 Point Replacement

### Deck Lift Assembly 3 Point Removal

1. Park the machine on a level surface set the parking brake. Stop the engine, wait for all moving parts to stop and remove the key.
2. To relieve tension on deck lift handle, place wood blocks (2x4) under each side of the deck. Lower the deck under tension is relieved from the lift handle.
3. Using a spring puller, remove the deck tension spring from the deck tension spring anchor.




g301964

**Figure 189**



## Deck Lift Assembly 3 Point Removal (continued)

4. Remove the deck belt from the PTO clutch.
5. Remove the cotter pin and washer (1 per side) from each side of the rear deck weldment securing the rear of deck to the deck lift hanger.



g301965

**Figure 190**

- 
6. Remove the rear lift arms from the deck weldments.
  7. Raise the deck lift handle to the transport position.
  8. Remove the cotter pin and washer securing the front deck hanger to front deck weldment. Remove the rod from the deck.



g301966

**Figure 191**

- 
9. Remove the wood blocks from under the deck.
  10. Slide the deck away from the machine.
  11. Flip the seat forward.

## Deck Lift Assembly 3 Point Removal (continued)

12. Using a T-30 torque bit, remove the 3 screws securing the pod to the pod support brackets. Repeat for opposite side.
13. Move the motion control from the neutral lock to the neutral position.
14. Using Philips head screw driver, remove the screw securing the smart speed knob to the smart speed lever. Remove the smart speed knob from the smart speed lever.



g301691

**Figure 192**

- 
15. Using a Philips head screw driver, remove the screw securing the control panel to the RH pod. Move the control panel to the side.




g301692

**Figure 193**

- 
16. Remove the RH pod from the machine.
  17. Lower the deck lift handle all the way to the bottom.

## Deck Lift Assembly 3 Point Removal (continued)

18. Remove the 2 hair pin and washers to disconnect the lift link from the deck lift bellcrank.



g301967

**Figure 194**

- 
19. Remove the 9/16 inch bolt and nut securing the lift link to the chassis. Repeat for opposite side.



g301968

**Figure 195**

- 
20. Raise the deck lift handle, remove the T-30 screw securing the height-of-cut bracket to the chassis.

## Deck Lift Assembly 3 Point Removal (continued)



g301969

**Figure 196**

- 
21. Remove the 2 screws securing the bellcrank retention bracket to the chassis. Repeat for opposite side.



g301970

**Figure 197**

---

## Deck Lift Assembly 3 Point Installation



1. Install the 2 screws securing the bellcrank retention bracket to the chassis. Repeat for opposite side. Torque screws to 17–22.5 N • m (150–200 in-lb).

## Deck Lift Assembly 3 Point Installation (continued)



g301970

**Figure 198**



2. Install the T-30 screw securing the height-of-cut bracket to the chassis. Lower the deck lift handle. Torque screw to 17–22.5 N • m (150–200 in-lb).



g301969

**Figure 199**



## Deck Lift Assembly 3 Point Installation (continued)

3. Install the 9/16 inch bolt and nut securing the lift link to the chassis. Repeat for opposite side. Torque bolt and nut to 40.5–44.5 N • m (30–33 ft-lb).



g301968

**Figure 200**

- 
4. Install the 2 hair pin and washers to connect the lift link to the deck lift bellcrank.



g301967

**Figure 201**

- 
5. Raise the deck lift handle.
  6. Place the RH pod into position on the machine.
  7. Install the control panel. Hand tighten with the screw securing the control panel to the RH pod.



## Deck Lift Assembly 3 Point Installation (continued)



g301692

**Figure 202**

8. Install the smart speed knob to the smart speed lever. Hand tighten with the screw securing the smart speed knob to the smart speed lever.



g301691

**Figure 203**

9. Move the motion control from the neutral position to the neutral lock position.
10. Install the 3 screws (per pod) securing the pod to the pod support brackets. Torque screws to 11 N • m (100 in-lb).
11. Flip the seat back into position.
12. Slide the deck into position under the machine.
13. Remove the wood blocks from under the deck.
14. Install the front deck hanger to the deck. Install the cotter pin and washer securing the front deck hanger to front deck weldment.



## Deck Lift Assembly 3 Point Installation (continued)



g301966

**Figure 204**

- 
15. Lower the deck lift handle to the lowest position.
  16. Install the rear lift arms to the deck weldments.
  17. Install the cotter pin and washer (1 per side) to each side of the rear deck weldment securing the rear of deck to the deck lift hanger.



g301965

**Figure 205**

- 
18. Install the deck belt to the PTO clutch.
  19. Using a spring puller, install the deck tension spring to the deck tension spring anchor.



## Deck Lift Assembly 3 Point Installation (continued)



g301964

**Figure 206**

- 
20. Raise the deck to add tension to the lift handle. Remove the wood blocks (2x4) under each side of the deck.

## Deck Lift Assembly 4 Point Replacement

### Deck Lift Assembly 4 Point Removal

1. Park the machine on a level surface and set the parking brake. Stop the engine, wait for all moving parts to stop and remove the key.
2. Place wood blocks (2x4) under each side of the deck.
3. To relieve tension on the height-of-cut pin, depress the foot lift handle and remove the height-of-cut pin from the height-of-cut gate.
4. Lower the deck onto the wood blocks.
5. Remove the LH 4 (3/8 inch) bolts securing the belt cover to the deck.
6. Using a spring puller, remove the deck tension spring from the deck tension spring anchor.
7. Remove the deck belt from the PTO clutch.
8. Remove the 2 (1/2 inch) bolts and 2 (9/16 inch) nuts securing the rear trailing arm to the deck.


## Deck Lift Assembly 4 Point Removal (continued)



g309653

**Figure 207**

- 
9. Remove the 2 (9/16 inch) nut and bolt securing the 2 RH lift links to the chassis. Remove the 2 RH lift links.



g309664

**Figure 208**

- 
10. Remove the 2 cotter pins and washers securing the deck lift links to the deck lift. Repeat for other side.
  11. Raise the deck lift into the highest height-of-cut position.
  12. Remove the deck from the machine.
  13. Remove the 2 (9/16 inch) bolts and nuts securing the center lift link to the front and rear bell cranks. Remove the center lift link.

## Deck Lift Assembly 4 Point Removal (continued)



g309675

**Figure 209**

14. Flip the seat forward.
15. Using a T-30 torque bit, remove the 3 screws securing the pod to the pod support brackets.
16. Move the motion control from the neutral lock to the neutral position.
17. Using Philips head screw driver, remove the screw securing the smart speed knob to the smart speed lever. Remove the smart speed knob from the smart speed lever.



g301691

**Figure 210**

18. Using a Philips head screw driver, remove the screw securing the control panel to the RH pod. Move the control panel to the side.

## Deck Lift Assembly 4 Point Removal (continued)



g301692

Figure 211

19. Remove the RH pod from the machine.
20. Remove the 2 (T-40) bolts securing the height-of-cut gate to chassis. Remove the height-of-cut gate.
21. Remove the 8 (T-40) bolts securing the front and rear bellcranks to the chassis. Remove the belle cranks.

## Deck Lift Assembly 4 Point Installation



1. Install the bellecrank. Install the 8 (T-40) bolts securing the front and rear bellcranks to the chassis. Torque bolts to 17–22.5 N • m (150–200 in-lb).



2. Install the height-of-cut gate. Install the 2 (T-40) bolts securing the height-of-cut gate to chassis. Torque bolts to 17–22.5 N • m (150–200 in-lb).
3. Place the RH pod into position on the machine.
4. Install the control panel. Hand tighten with the screw securing the control panel to the RH pod.
5. Install the smart speed knob to the smart speed lever. Hand tighten with the screw securing the smart speed knob to the smart speed lever.
6. Move the motion control from the neutral position to the neutral lock position.



7. Install the 3 screws (per pod) securing the pod to the pod support brackets. Torque screws to 11 N • m (100 in-lb).

8. Flip the seat back into position.



9. Install the center lift link. Install the 2 (9/16 inch) bolts and nuts securing the center lift link to the front and rear bell cranks. Torque bolts and nuts to 40.5–44.5 N • m (30–33 ft-lb).

10. Install the deck to the machine.

11. Lower the deck lift into the lowest position.

## Deck Lift Assembly 4 Point Installation (continued)

12. Install the 2 cotter pins and washers securing the deck lift links to the deck lift. Repeat for other side.



13. Install the 2 RH lift links. Install the 2 (9/16 inch) nuts and bolts securing the 2 RH lift links to the chassis. Torque bolts and nuts to 40.5–44.5 N • m (30–33 ft-lb).



14. Install the 2 (1/2 inch) bolts and 2 (9/16 inch) nuts securing the rear trailing arm to the deck. Torque bolts and nuts to 40.5–44.5 N • m (30–33 ft-lb).

15. Install the deck belt to the PTO clutch.

16. Using a spring puller, install the deck tension spring to the deck tension spring anchor.



17. Install the LH 4 (3/8 inch) bolts securing the belt cover to the deck. Torque bolts to 19.5–22.5 N • m (175–200 in-lb).

18. Raise the deck off the wood blocks.

19. Install the height-of-cut pin to the height-of-cut gate. Add tension to the height-of-cut pin.

## Front Chassis Storage Box Replacement

### Front Chassis Storage Box Removal

1. Park the machine on a level surface and set the parking brake. Stop the engine, wait for all moving parts to stop and remove the key.
2. Remove the 2 (9/16 inch) bolt from the front license plate.



g301973

Figure 212

3. Lift up and remove the license plate from the chassis.

## Front Chassis Storage Box Removal (continued)



g301974

**Figure 213**




g301975

**Figure 214**

4. Remove the floor pan from the chassis.
5. Remove the 2 front pod mounting screws (T-30).
6. Remove the 2 screws (T-20) securing the cubbie to the chassis.

## Front Chassis Storage Box Removal (continued)




g301788

**Figure 215**

7. Move the smart speed selector to the turtle/trim position.
8. Remove the cubbie by lifting the front of each pod to maneuver the cubbie away from the chassis.

## Front Chassis Storage Box Installation

1. Install the cubbie onto the machine.
2. Move the smart speed selector to turtle/trim position.
3. Install the 2 screws (T-20) securing the cubbie to the chassis. Torque screws to 11 N • m (100 in-lb).



g301788

**Figure 216**

## Front Chassis Storage Box Installation (continued)



4. Install the 2 front pod mounting screws (T-30). Torque screws to 11 N • m (100 in-lb).

5. Install the floor pan to the chassis.



6. Install the 4 (T-30) screws securing the floor pan to the chassis. Torque screws to 17–22.5 N • m (150–200 in-lb).



g301975

Figure 217

---

7. Install the license plate to the chassis.



g301974

Figure 218





## Front Chassis Storage Box Installation (continued)

8. Install the 2 (9/16 inch) bolt to the front license plate. Torque screws to 22.5–25 N • m (200–225 in-lb).



g301973

**Figure 219**





# Hydrostatic Drive System

## Table of Contents

General Information .....	6-2
Service and Repairs .....	6-3
Hydro Transaxle Drive Belt Replacement .....	6-5
Neutral Adjustment .....	6-9
Air Purging Procedure .....	6-12
Hydro Transaxle Replacement.....	6-12


# General Information

The TIMECUTTER® series of mowers use Hydro-Gear hydrostatic transaxles. There are 4 different models used; ZT-2100, ZT-2200, ZT-2200 long axle, and ZT-2800. All the drives use the same type of fluid. The oil must have a minimum rating of 9.0 cSt (55 SUS) at 230°F (110°C) with an API classification of SL is recommended. A 20W-50 engine oil has been selected for use by the factory and is recommended for normal operating procedures. An oil volume of 54 fl oz for the ZT-2100 and 56 fl oz for the ZT-2200 should bring the fluid to the correct level in the transaxle.

See the [Hydro-Gear](#) manufacturer's manual for servicing.

# Service and Repairs

## Hydrostatic Drive Asm. 1




g306748

**Figure 220**

- |                      |                             |
|----------------------|-----------------------------|
| 1. V-belt            | 7. Pedal Return Spring      |
| 2. RH Bypass Rod     | 8. RH Hydro Transaxle Asm.  |
| 3. Spacer            | 9. Hydro Cross Plate        |
| 4. Idler             | 10. LH Hydro Transaxle Asm. |
| 5. Idler Arm         | 11. LH Bypass Rod           |
| 6. Flat Idler Pulley |                             |

## Hydrostatic Drive Asm. 2



g306774

**Figure 221**

- |                  |                             |
|------------------|-----------------------------|
| 1. Breather Kit  | 8. Flat Idler Pulley        |
| 2. Hydro Hose    | 9. Pedal Return Spring      |
| 3. RH Bypass Rod | 10. Bracket Mount           |
| 4. V-belt        | 11. RH Hydro Transaxle Asm. |
| 5. Spacer        | 12. Hydro Plate             |
| 6. Idler         | 13. LH Hydro Transaxle Asm. |
| 7. Idler Arm     | 14. LH Bypass Rod           |

# Hydro Transaxle Drive Belt Replacement

## Hydro Transaxle Drive Belt Removal

1. Park the machine on a level surface and set the parking brake. Stop the engine, wait for all moving parts to stop and remove the key.
2. Disconnect the battery by removing the negative battery cable first, then the positive cable from the battery.
3. Remove 10 (T-40) self-tapping screws securing the rear engine guard and muffler shield to the chassis. Remove the muffler shield and rear engine guard.



g300621

**Figure 222**

- 
4. Remove the deck tensioner spring from the spring hook.



g300623

**Figure 223**

- 
5. Using an appropriate lifting device, raise the machine. Remove the deck belt from the clutch pulley.

## Hydro Transaxle Drive Belt Removal (continued)

6. Disconnect the wiring to the clutch.



g300624

**Figure 224**

- 
7. Remove the 5/8 hex bolt securing the clutch to the crankshaft of the engine. Remove the clutch.



g300625

**Figure 225**

- 
8. Remove the hydro belt tensioner spring from the spring anchor point on the chassis.



## Hydro Transaxle Drive Belt Removal (continued)



g300671

**Figure 226**

9. Remove the hydro belt tensioner spring from the spring anchor point on the chassis.
10. Remove the drive belt from the machine.

## Hydro Transaxle Drive Belt Installation

1. Install the hydro transaxle drive belt to the machine. Install the hydro transaxle drive belt onto the engine pulley, both transaxle pulleys, fixed idler, and movable idler pulleys.
2. Install the hydro belt tensioner spring to the spring anchor point on the chassis.



g300671

**Figure 227**



3. Install the clutch. Install the 5/8 hex bolt securing the clutch to the crankshaft of the engine. Torque bolt to 71–81 N • m (53–60 ft-lb).

## Hydro Transaxle Drive Belt Installation (continued)



g300625

**Figure 228**

- 
4. Connect the wiring to the clutch.



g300624

**Figure 229**

- 
5. Install the deck belt to the clutch pulley. Using an appropriate lifting device, lower the machine.
  6. Install the deck tensioner spring to the spring hook.

## Hydro Transaxle Drive Belt Installation (continued)



g300623

**Figure 230**



7. Install the muffler shield and rear engine guard. Install 10 (T-40) self-tapping screws securing the rear engine guard and muffler shield to the chassis. Torque screws to 17–22.5 N • m (150–200 in-lb).



g300621

**Figure 231**


8. Connect the battery by installing the positive battery cable first, then the negative cable to the battery.

## Neutral Adjustment

1. Park the machine on a level surface and set the parking brake. Stop the engine, wait for all moving parts to stop and remove the key.
2. Using an appropriate lifting device, raise and support the rear of the machine.

## Neutral Adjustment (continued)

3. Remove the 4 (13/16 inch) lug nuts securing rear wheel to the hub. Remove the wheel from the machine.
4. Disconnect the seat switch.



g302064

**Figure 232**

- 
5. Install an appropriate jumper to disable the seat switch.
  6. Start the machine.
  7. Move the motion control lever until neutral is found. Once neutral is found, install an M8X1.00 nut onto the neutral lock stud for the transmission.



g302065

**Figure 233**

- 
8. Tighten the nut to lock the neutral position.
  9. Loosen the 7/16 inch nut securing the 2 motion control levers.

## Neutral Adjustment (continued)



g302066

**Figure 234**

10. Adjust the motion control lever to access the parking brake position. Tighten the 7/16 inch nut securing the 2 motion control levers.
11. Repeat for opposite side.
12. Perform the Tracking Adjustment procedure after neutral adjustment has been completed for both sides.
13. Remove the M8X1.00 nut on the neutral lock stud of the transmission.
14. Connect the seat switch.



15. Install the wheel to the machine. Install the 4 (13/16 inch) lug nuts securing the rear wheel to the hub. Torque the lug nuts to 94.5–122 N • m (70–90 ft-lb).



g302065

**Figure 235**

## Air Purging Procedure

Due to the effects air has on efficiency in hydrostatic drive applications, it is critical that it is purged from the system. These purge procedures should be implemented any time a hydrostatic system has been opened to facilitate maintenance or any additional oil has been added to the system.

The following procedures should be performed with the vehicle drive wheels off the ground, then repeated under normal operating conditions. Before starting, make sure the transaxle/transmission is at the proper oil level.

1. With the bypass valve open and the engine running, slowly move the directional control in both forward and reverse directions (5 or 6 times), as air is purged from the unit, the oil level will drop.
2. With the bypass valve closed and the engine running, slowly move the directional control in both forward and reverse directions (5 to 6 times). Check the oil level, and add oil as required after stopping the engine.
3. It may be necessary to repeat Steps 1 and 2 until all the air is completely purged from the system. When the transaxle moves forward and reverse at normal speed purging is complete.

## Hydro Transaxle Replacement

### Hydro Transaxle Removal

1. Park the machine on a level surface and set the parking brake. Stop the engine, wait for all moving parts to stop and remove the key.
2. Disconnect the battery by removing the negative battery cable first, then the positive cable from the battery.
3. Using an appropriate lifting device, raise the rear of the machine.
4. Remove the 13/16 inch lug nut securing the wheel to the transaxle hub.
5. Remove the wheel from the transaxle hub.
6. Remove the cotter pin and washer securing the dump valve rod to the transaxle. Remove the dump valve rod linkage from the transaxle.



g302067

Figure 236

## Hydro Transaxle Removal (continued)



g302068

**Figure 237**

- 
7. Remove the cotter pin and washer securing the brake rod linkage to the brake box. Remove the brake rod linkage from the brake box.



g309739

**Figure 238**

- 
8. Remove the  $\frac{1}{2}$  nut and  $\frac{5}{8}$  bolt securing the motion control linkage to the transaxle. Remove the motion control linkage.


## Hydro Transaxle Removal (continued)



g302069

**Figure 239**

- 
9. Using a spring puller, remove the hydro transaxle drive belt tension spring.



g302070

**Figure 240**

- 
10. Remove the drive belt from the transaxle pulley.




## Hydro Transaxle Removal (continued)



g302071

**Figure 241**

- 
11. Remove the 4 (1/2 inch) bolts and nuts, 3 (11/16 inch) nuts and 3 (5/8 inch) bolts securing the transaxle to the chassis.



g302073


**Figure 242**

---

## Hydro Transaxle Installation

1. Install the transaxle to the chassis.

## Hydro Transaxle Installation (continued)



g302073

**Figure 243**



2. Install, but do not tighten, the 4 (1/2 inch) bolts and nuts, 3 (5/8 inch) bolts, and 11/16 inch nut securing the transaxle to the chassis. See torque sequence below.
  - A. Torque the (5/8 inch) front inner mounting bolt and (11/16 inch) nut to the frame bracket to 67.5–74.5 N • m (50–55 ft-lb).
  - B. Torque the 2 (5/8 inch) bottom mounting bolts and (11/16 inch) nuts to the cross plate to 67.5–74.5 N • m (50–55 ft-lb).
  - C. Torque the 2 (1/2 inch) front and rear mid-mounting bolts and nuts to the chassis to 22.5–25 N • m (200–225 in-lb).
  - D. Torque the 2 (1/2 inch) axle mounting bolts and nuts to the frame bracket to 22.5–25 N • m (200–225 in-lb).



g302071

**Figure 244**

## Hydro Transaxle Installation (continued)

3. Install the drive belt to the transaxle pulley.
4. Using a spring puller, install the hydro transaxle drive belt traction spring.



g302070

**Figure 245**



5. Install the motion control linkage. Install the  $\frac{1}{2}$  nut and  $\frac{5}{8}$  bolt securing the motion control linkage to the transaxle. Torque nut and bolt to 22.5–25 N • m (200–225 in-lb).



g302069

**Figure 246**

6. Install the brake rod linkage to the brake box. Install the cotter pin and washer securing the brake rod linkage to the brake box.
7. Install the dump valve rod linkage to the transaxle. Install the cotter pin and washer securing the dump valve rod to the transaxle.

## Hydro Transaxle Installation (continued)



g302067

**Figure 247**



g302068

**Figure 248**

8. Install the wheel to the transaxle hub.
9. Install the 13/16 inch lug nut securing the wheel to the transaxle hub. Torque lug nut to 94.5–122 N • m (70–90 ft-lb).
10. Using an appropriate lifting device, lower the rear of the machine.
11. Connect the battery by installing the positive battery cable first, then the negative cable to the battery.



# Mower Deck System

## Table of Contents


General Information ..... 7-2  
Service and Repairs ..... 7-3  
    42 inch Stamped and 42/50/54/60 Inch Fabricated Deck Replacement..... 7-8

# General Information

The TIMECUTTER® series of mowers uses 5 different deck sizes offering both fabricated and stamped options; 32 inch stamped deck, 42 inch stamped, 42 inch fabricated, 50 inch fabricated, 54 inch fabricated, and 60 inch fabricated. There are 2 different deck lift systems a 3-point system used on 32–54 inch units and a 4-point system used only on 60 inch units. All units have a 1.5-4.5 inch height-of-cut range.

# Service and Repairs

## Mower Deck Assembly 1–42 Inch Stamped Deck




g307745

**Figure 249**

- |                                      |                                      |
|--------------------------------------|--------------------------------------|
| 1. Right Guard Asm. (CE Models Only) | 15. Extension Spring                 |
| 2. Guard Mount Plate                 | 16. Front Shield                     |
| 3. 42 Inch Mulch Plug Asm.           | 17. Spring Return Hook               |
| 4. Belt Cover                        | 18. 42 Inch Deck                     |
| 5. Pulley                            | 19. Deck Pin                         |
| 6. Flat Idler Pulley                 | 20. Rear Blowout Baffle              |
| 7. V-Belt                            | 21. Washout Fitting                  |
| 8. Belt Idler Guide                  | 22. Clipping Baffle                  |
| 9. Idler Arm                         | 23. Spindle Asm.                     |
| 10. Deflector                        | 24. Side Blowout Baffle              |
| 11. Pivot Rod                        | 25. Left Guard Asm. (CE Models Only) |
| 12. Deflector Insert                 | 26. Spindle Shaft                    |
| 13. Torsion Spring                   | 27. Mulch Blade                      |
| 14. Anti Scalp Roller                |                                      |

# Mower Deck Assembly 2-42 Inch Fabricated Deck




g307880

**Figure 250**

- |                                      |                                      |
|--------------------------------------|--------------------------------------|
| 1. Belt Cover                        | 13. 42 Inch Fabricated Deck          |
| 2. V-Belt                            | 14. Washout Fitting                  |
| 3. Guard Mount Plate                 | 15. Left Guard Asm. (CE Models Only) |
| 4. Right Guard Asm. (CE Models Only) | 16. Anti Scalp Roller                |
| 5. Pulley                            | 17. Extension Spring                 |
| 6. Belt Cover Bracket                | 18. Return Spring Hook               |
| 7. Front Shield                      | 19. Deck Pin                         |
| 8. Flat Idler Pulley                 | 20. Recycling Baffle                 |
| 9. Idler Arm                         | 21. 42 Inch Deflector                |
| 10. Torsion Spring                   | 22. Spindle Asm.                     |
| 11. Discharge Deflector              | 23. Spindle Shaft                    |
| 12. Pivot Rod                        | 24. Blade                            |



## Mower Deck Assembly 3–50 Inch Fabricated Deck




g308181

**Figure 251**

- |                                      |                             |
|--------------------------------------|-----------------------------|
| 1. Belt Cover                        | 14. Anti Scalp Roller       |
| 2. V-Belt                            | 15. Pulley                  |
| 3. Flat Idler Pulley                 | 16. Deck Pin                |
| 4. Guard Mount Plate                 | 17. Washout Fitting         |
| 5. Right Guard Asm. (CE Models Only) | 18. Front Shield            |
| 6. Pulley                            | 19. 50 Inch Fabricated Deck |
| 7. Belt Cover Bracket                | 20. Extension Spring        |
| 8. Flat Idler Pulley                 | 21. Spring Return Hook      |
| 9. Idler Belt Guide                  | 22. Corner Baffle           |
| 10. Left Guard Asm. (CE Models Only) | 23. 50 Inch Baffle Asm.     |
| 11. Pivot Rod                        | 24. Spindle Asm.            |
| 12. Torsion Spring                   | 25. Spindle Shaft           |
| 13. Discharge Deflector              | 26. Mulch Blade             |

## Mower Deck Assembly 4– 54 Inch Fabricated Deck




g308186

**Figure 252**

- |                        |                        |
|------------------------|------------------------|
| 1. Belt Cover          | 12. Idler Arm          |
| 2. Belt Cover Bracket  | 13. Spring Return Hook |
| 3. V-Belt              | 14. Deck Pin           |
| 4. Discharge Deflector | 15. Washout Fitting    |
| 5. Torsion Spring      | 16. Hose Connector     |
| 6. Pivot Rod           | 17. Anti Scalp Roller  |
| 7. Cut-off Baffle      | 18. Spindle Asm.       |
| 8. Pulley Asm.         | 19. 54 Inch Deck Asm.  |
| 9. Idler Belt Guide    | 20. Corner Baffle      |
| 10. Flat Idler Pulley  | 21. Spindle Shaft      |
| 11. Extension Spring   | 22. Hi Lift Blade      |

## Mower Deck Assembly 5–60 Inch Fabricated Deck



g308211

**Figure 253**

- |                        |                             |
|------------------------|-----------------------------|
| 1. RH Belt Cover       | 11. Anti Scalp Roller       |
| 2. LH Belt Cover       | 12. Extension Spring        |
| 3. Belt                | 13. Spring Return Hook      |
| 4. Discharge Deflector | 14. Washout Fitting         |
| 5. Pivot Rod           | 15. Hose Connector          |
| 6. Torsion Spring      | 16. 60 Inch Deck Fabricated |
| 7. Cutoff Baffle       | 17. Spindle Asm.            |
| 8. Pulley              | 18. Corner Baffle           |
| 9. Flat Idler Pulley   | 19. Spindle Shaft           |
| 10. Idler Arm          | 20. Hi Flow Blade           |

# 42 inch Stamped and 42/50/54/60 Inch Fabricated Deck Replacement

## 42 inch Stamped and 42/50/54/60 Inch Fabricated Deck Removal

**Note:** The following procedure shows the 42 inch stamped deck.

1. Park the machine on a level surface and set the parking brake. Stop the engine, wait for all moving parts to stop and remove the key.
2. Using a spring puller, remove the deck tension spring from the deck tension spring anchor.
3. Remove the deck belt from the PTO clutch.
4. Remove the cotter pin and washer (1 per side) from each side of the rear deck weldment securing the rear of deck to the deck lift hanger.
5. Remove the rear lift arms from the deck weldments.
6. Raise the deck lift handle to the transport position.
7. Remove the cotter pin and washer securing the front deck hanger to front deck weldment. Remove the rod from the deck.
8. Remove the wood blocks from under the deck.
9. Slide the deck away from the machine.



g302087

Figure 254


---

## 42 inch Stamped and 42/50/54/60 Inch Fabricated Deck Disassembly

**Note:** Belt covers are toolless removal on 42–54 inch fabricated decks, CE requires tools to remove.

1. Remove the 6 (5/16 inch) screws securing the LH and RH belt covers. Remove the LH and RH belt covers.

## 42 inch Stamped and 42/50/54/60 Inch Fabricated Deck Disassembly (continued)



g302088

**Figure 255**

- 
- Using a  $\frac{9}{16}$  inch wrench to hold the bolt, remove the  $\frac{9}{16}$  inch nut securing the belt guide to the movable idler. Remove the belt guide from the deck.



g302089

**Figure 256**

- 
- Remove the belt from the deck.


## 42 inch Stamped and 42/50/54/60 Inch Fabricated Deck Disassembly (continued)



g302090

**Figure 257**

4. Remove the deck tension spring from the deck.
5. Remove the spring anchor from the deck.
6. Before idler arm removal, ensure idler arm has tension to prevent limited movement (should not move freely).
7. Remove the moveable idler from the deck and flat washers.



g302091

**Figure 258**

8. Remove the 9/16 inch bolt and nut securing the idler arm to the deck shell.

## 42 inch Stamped and 42/50/54/60 Inch Fabricated Deck Disassembly (continued)



g302092

**Figure 259**

9. Using an appropriate blade holding device, remove the 5/8 inch bolt securing the blade to the deck. Remove the blade from the deck.
10. Remove the 15/16 inch nut securing the spindle to the spindle shaft.
11. Remove the pulley from the spindle shaft.
12. Remove the 4 (1/2 inch) screws securing spindle to the deck assembly. Remove the spindle assembly.



g309761





**Figure 260**

13. Remove the spindle from the spindle assembly.
14. Using a drift punch, remove the bearings from the spindle housing. Replace as necessary.

## 42 inch Stamped and 42/50/54/60 Inch Fabricated Deck Assembly

1. Using an appropriate sized socket, install the bearings to the spindle housing.

## 42 inch Stamped and 42/50/54/60 Inch Fabricated Deck Assembly (continued)

2. Install the spindle to the spindle assembly.
-  3. Install the spindle assembly. Install the 4 (1/2 inch) screws securing spindle to the deck assembly. Torque screws to 19.5–22.5 N • m (175–225 in-lb).
4. Install the pulley to the spindle shaft.
-  5. Install the 15/16 inch nut securing the spindle to the spindle shaft. Torque nut to 67.5–88 N • m (50–65 ft-lb).
-  6. Install the blade to the deck. Using an appropriate blade holding device, install the 5/8 inch bolt securing the blade to the deck. Torque bolt to 95–108 N • m (70–80 ft-lb).
-  7. Install the 9/16 in. bolt and nut securing the idler arm to the deck shell. Torque bolt and nut to 40.5–44.5 N • m (30–33 ft-lb).




g302092

**Figure 261**

- 
8. Install the moveable idler to the deck and flat washers.



## 42 inch Stamped and 42/50/54/60 Inch Fabricated Deck Assembly (continued)



g302091

**Figure 262**

9. Before idler arm removal, ensure idler arm has tension to prevent limited movement (should not move freely).
10. Install the spring anchor to the deck.
11. Install the deck tension spring to the deck.
12. Install the belt to the deck.



g302090

**Figure 263**



13. Install the belt guide to the deck. Using a 9/16 inch wrench to hold the bolt, install the 9/16 inch nut securing the belt guide to the movable idler. Torque nut to 40.5–44.5 N • m (30–33 ft-lb).

## 42 inch Stamped and 42/50/54/60 Inch Fabricated Deck Assembly (continued)



g302089

Figure 264



14. Install the LH and RH belt covers. Install the 6 (5/16 inch) screws securing the LH and RH belt covers. Torque screws to 4.5–5 N • m (42–47 in-lb).



g302088

Figure 265

## 42 inch Stamped and 42/50/54/60 Inch Fabricated Deck Installation

1. Slide the deck into position under the machine.

## 42 inch Stamped and 42/50/54/60 Inch Fabricated Deck Installation (continued)



g302087

**Figure 266**

2. Install the wood blocks under the deck.
3. Install the front hanger rod to the deck. Install the cotter pin and washer securing the front deck hanger to front deck weldment.
4. Lower the deck lift handle to the lowest position.
5. Install the rear lift arms to the deck weldments.
6. Install the cotter pin and washer (1 per side) to each side of the rear deck weldment securing the rear of deck to the deck lift hanger.
7. Install the deck belt to the PTO clutch.
8. Using a spring puller, install the deck tension spring to the deck tension spring anchor.
9. Raise the deck to add tension to the lift handle.





## Table of Contents


General Information .....	8-2
Service and Repairs .....	8-3
PTO Clutch Replacement .....	8-5
Motion Control and Seat Switch Replacement .....	8-9
Brake Module Replacement.....	8-12
PTO Switch Replacement .....	8-13
Ignition Switch Replacement.....	8-16
Starter Solenoid Replacement .....	8-19

# General Information

The TIMECUTTER® series of mowers utilizes a 12VDC electrical system. The system consists of 2 different 12v batteries; 195 CCA and 230 CCA (depending on the model). The electrical system uses 2 neutral/park switches on the motion control levers, seat switch, electronic brake actuator (brake box), blade engagement switch (PTO), ignition switch, main/charge system fuse 25A, and a system fuse 15A.

# Service and Repairs


## Electrical Assembly 1



g308357

**Figure 267**

- |                    |                            |
|--------------------|----------------------------|
| 1. Rubber Strap    | 8. Positive Battery Cable  |
| 2. Ignition Key    | 9. Wire Harness            |
| 3. Ignition Switch | 10. Solenoid Cover         |
| 4. PTO Switch      | 11. Negative Battery Cable |
| 5. Solenoid Cap    | 12. Positive Battery Cable |
| 6. Harness Clip    | 13. Solenoid               |
| 7. Switch          | 14. Battery                |



g308358

**Figure 268**

- 1. Clutch Stop
- 2. Engine Pulley
- 3. Clutch Isolator
- 4. PTO Clutch



# PTO Clutch Replacement

## PTO Clutch Removal

1. Park the machine on a level surface and set the parking brake. Stop the engine, wait for all moving parts to stop and remove the key.
2. Disconnect the battery by removing the negative battery cable first, then the positive cable from the battery.
3. Using an appropriate lifting device, raise the machine. Remove the deck belt from the clutch pulley.
4. Disconnect the wiring to the clutch.



g300624

Figure 269

- 
5. Remove the 5/8 hex bolt securing the clutch to the crankshaft of the engine. Remove the clutch.



g300625

Figure 270

---

## PTO Clutch Installation



1. Install the clutch. Install the 5/8 hex bolt securing the clutch to the crankshaft of the engine. Torque bolt to 67.5–81 N • m (50–60 ft-lb).

## PTO Clutch Installation (continued)



g300625

**Figure 271**

- 
2. Connect the wiring to the clutch.



g300624


**Figure 272**

- 
3. Install the deck belt to the clutch pulley.
  4. Using an appropriate lifting device, lower the machine.
  5. Connect the positive battery cable first, then the negative battery cable to the battery.

## PTO Clutch Testing

1. Park the machine on a level surface and set the parking brake. Stop the engine, wait for all moving parts to stop and remove the key.
2. Disconnect the clutch wire connector.
3. Set the multi-meter to measure resistance (OHMs setting).
4. Connect the meter lead wires to the terminals in the clutch connector.

## PTO Clutch Testing (continued)



g309780

Figure 273


5. See the PTO Clutch Electrical Specifications chart below:

Model Number	Resistance (OHMs)	AMP Draw	Continuity to Ground
74694, 75750, 75751, 75753, 75755, 75759	3.69 ± 5%	3.25A	Open
75755TA, 75754, 75757, 75760	3.05 ± 5%	3.93A	Open
74685, 74687, 74690, 75742TA, 75745TA, 75740, 75741, 75742, 75743, 75744, 75745	3.02 ± 5%	3.97A	Open
74710	3.02 ± 5%	3.97A	Open

### PTO Clutch Continuity to Ground Check

1. Park the machine on a level surface and set the parking brake. Stop the engine, wait for all moving parts to stop and remove the key.
2. Disconnect the clutch wire connector.
3. Set the multi-meter to measure resistance (OHM setting).
4. Connect one multi-meter lead to the engine, chassis or battery ground. Connect the other multi-meter lead to each of the clutch connector terminals.
5. The 2 clutch connector terminals should never have continuity to ground and should OPEN at all times.
6. If continuity is found between the PTO connector and ground, the PTO clutch and the PTO switch must be replaced.

## PTO Clutch Continuity to Ground Check (continued)



g309780


Figure 274

## PTO Clutch Measuring Clutch Current Draw

Do not measure current draw if the clutch has shorted to ground or if the resistance measurement is out of specification.

1. Park the machine on a level surface and set the parking brake. Stop the engine, wait for all moving parts to stop and remove the key.
2. Disconnect the clutch wire connector.
3. Set the multi-meter to measure amps (10 amp scale).
4. Connect the positive meter lead to the chassis harness terminal A.
5. Connect the negative meter lead to the corresponding wire terminal B.
6. Connect a short jumper lead from terminal C to terminal D.

**Note:** Connector shape may vary per model.



g309801

Figure 275

7. Turn the ignition switch to RUN and the PTO switch to the ON position.

## PTO Clutch Measuring Clutch Current Draw (continued)

8. Record the amp reading and refer to the PTO Clutch Electrical Specification Chart above.

## Motion Control and Seat Switch Replacement

### Motion Control and Seat Switch Removal

1. Park the machine on a level surface and set the parking brake. Stop the engine, wait for all moving parts to stop and remove the key.
2. Flip the seat forward.
3. Using a T-30 torque bit, remove the 3 screws securing the pod to the pod support brackets. Repeat for opposite side.
4. Remove the fuel cap on the LH side pod.
5. Move the motion control from the neutral lock to the neutral position.
6. Remove the LH pod from the machine.

**Note:** The LH and RH pod removal are the same except the RH pod has the control panel and smart speed knob.

7. Using Philips head screw driver, remove the screw securing the smart speed knob to the smart speed lever. Remove the smart speed knob from the smart speed lever.



g301691

**Figure 276**

- 
8. Using a Philips head screw driver, remove the screw securing the control panel to the RH pod. Move the control panel to the side.

## Motion Control and Seat Switch Removal (continued)



g301692

**Figure 277**

9. Remove the RH pod from the machine.
10. Disconnect the motion control neutral switch from the steering control box by depressing the tabs on either side of the switch. Disconnect the switch from the connector.

## Motion Control and Seat Switch Installation

1. Connect the switch to the connector. Connect the motion control neutral switch to the steering control box by depressing the tabs on either side of the switch.
2. Place the RH pod into position on the machine.
3. Install the control panel. Hand tighten with the screw securing the control panel to the RH pod.



g301692

**Figure 278**

## Motion Control and Seat Switch Installation (continued)

4. Install the smart speed knob to the smart speed lever. Hand tighten with the screw securing the smart speed knob to the smart speed lever.



g301691

Figure 279

5. Place the LH pod into position on the machine.
6. Move the motion control from the neutral position to the neutral lock position.
7. Install the fuel cap on the LH side pod.
8. Install the 3 screws (per pod) securing the pod to the pod support brackets. Torque screws to 11 N • m (100 in-lb).
9. Flip the seat back into position.



## Seat Switch Testing

1. Disconnect the wire harness from the Operator Presence Switch (seat switch), located on the bottom of the seat assembly.
2. Using a digital multi-meter set to the OHM or Continuity setting, test the continuity between the two switch terminals.
  - When the seat is vacated, the switch should NOT have continuity (open)
  - When the operator is present, the switch should have continuity (closed)

## Neutral Lock Switch Testing


The neutral switch is a single pole plunger type switch (normally open) with two terminals. When the plunger is depressed, the circuit closes and there is continuity between the terminals.

- Motion Control Levers in neutral park position (OUT), the switch should have continuity (closed)
- Motion Control Levers in the operating position (IN), the switch should NOT have continuity (open)

# Brake Module Replacement

## Brake Module Removal


1. Park the machine on a level surface and set the parking brake. Stop the engine, wait for all moving parts to stop and remove the key.
2. Flip the seat forward.
3. Disconnect the battery by removing the negative battery cable first, then the positive cable from the battery.
4. Depress the tab on the top of the connector to release the connector from the module.



g302093

**Figure 280**

- 
5. Remove the 2 (3/8) screws securing the brake module bracket to the chassis. Remove the brake module.
  6. Remove the 4 Philips head screws securing the bracket to the brake module.



g302094


**Figure 281**



## Brake Module Installation



1. Install and hand tighten the 4 Philips head screws securing the bracket to the module. Place the brake module into position on the machine.
2. Install the 2 (3/8 inch) screws securing the brake module bracket to the chassis. Torque screws to 9–11 N • m (80–100 in-lb).
3. Install the connector to the module.



g302093

**Figure 282**


- 
4. Install the 2 cotter pins and flat washers securing the brake rods to the brake module.
  5. Flip the seat into operating position.
  6. Connect the battery by installing the positive battery cable first, then the negative cable to the battery.

## PTO Switch Replacement

### PTO Switch Removal

1. Park the machine on a level surface and set the parking brake. Stop the engine, wait for all moving parts to stop and remove the key.
2. Disconnect the battery by removing the negative battery cable first, then the positive cable from the battery.
3. Remove the Philips head screw from the control panel.
4. Disconnect the PTO switch.


## PTO Switch Removal (continued)



g302095

**Figure 283**

- 
5. Depress the tabs on the side of the switch and remove the switch from the control panel.



g302097


**Figure 284**

---

## PTO Switch Installation

1. Install the switch to the control panel.


## PTO Switch Installation (continued)



g302097

**Figure 285**

2. Connect the PTO switch.
3. Install and hand tighten the Philips head screw to the control panel.



g302095


**Figure 286**

4. Connect the battery by installing the positive battery cable first, then the negative cable to the battery.

## PTO Switch Testing

1. Remove the control panel from the right console.
2. Disconnect the PTO switch from the wire harness.
3. With the switch in the ON position (button pulled OUT).

## PTO Switch Testing (continued)



g316660

Figure 287


4. Using a digital multi-meter set to the OHM or Continuity setting, verify the following:
  - Pin 2 and 5 should have continuity (closed)
  - Pin 1 and 4 should have continuity (closed)
  - Pin 1 and 7 should NOT have continuity (open)
  - Pin 2 and 8 should NOT have continuity (open)
5. With the switch in the OFF position (button pushed IN):
  - Pin 1 and 7 should have continuity (closed)
  - Pin 2 and 8 should have continuity (closed)
  - Pin 1 and 4 should NOT have continuity (open)
  - Pin 2 and 5 should NOT have continuity (open)

## Ignition Switch Replacement

### Ignition Switch Removal

1. Park the machine on a level surface and set the parking brake. Stop the engine, wait for all moving parts to stop and remove the key.
2. Disconnect the battery by removing the negative battery cable first, then the positive cable from the battery.
3. Remove the Philips head screw from the control panel.
4. Disconnect the ignition switch.


## Ignition Switch Removal (continued)



g302096

**Figure 288**

- 
5. Depress the tabs on the side of the switch and remove the switch from the control panel.



g302112


**Figure 289**

---

## Ignition Switch Installation

1. Install the switch to the control panel.


## Ignition Switch Installation (continued)



g302112

**Figure 290**

- 
2. Connect the ignition switch.



g302096

**Figure 291**


- 
3. Install and hand tighten the Philips head screw to the control panel.
  4. Connect the battery by installing the positive battery cable first, then the negative cable to the battery.

## Ignition Switch Testing

The ignition switch makes the proper connections for the starter, safety circuits, and accessories. Detents inside the switch control the three switch positions: OFF, RUN, and START. The START position is spring loaded so that it automatically returns to the RUN position when released.

### Ignition Switch Wiring Connections

## Ignition Switch Testing (continued)



g316681

Figure 292

- 1 — Starting Circuit Terminal
  - 2 — (No connection)
  - 3 — Battery Terminal
  - 4 — Seat Switch and Hour Meter Terminal
  - 5 — PTO Switch Terminal
1. Remove the control panel from the right console.
  2. Disconnect the harness from the ignition switch. Gently rock the connector back and forth until unplugged.
  3. Using a digital multi-meter set to the OHM or Continuity setting, verify that continuity exists between the terminals listed for each switch position.
  4. Using a digital multi-meter set to the OHM or Continuity setting, verify that NO continuity exists between the terminals not listed for each switch position.


Position	Circuit "Make"
1. OFF	None
2. RUN	2 + 3 + 5 + 4
3. START	2 + 3 + 5 + 1

## Starter Solenoid Replacement

### Starter Solenoid Removal

1. Park the machine on a level surface and set the parking brake. Stop the engine, wait for all moving parts to stop and remove the key.
2. Flip the operator's seat forward.
3. Disconnect the battery by removing the negative battery cable first, then the positive cable from the battery.
4. Using a flat head screw driver, pry the solenoid terminal cover off to release the tabs on the solenoid cover.

## Starter Solenoid Removal (continued)




g302124

**Figure 293**

5. Remove the 2 (½ inch) nuts securing the battery cable and the starter power cable to the starter solenoid.

**Note:** The battery cable side has an additional red wire for the chassis harness.




g302125

**Figure 294**

6. Remove the blue and green wires from the main harness to the starter solenoid.



## Starter Solenoid Removal (continued)



g302126

Figure 295

7. Remove the 2 (3/8 inch) bolts securing the starter solenoid to the chassis.



g302127

Figure 296

8. Remove the starter solenoid from the chassis.

## Starter Solenoid Installation



1. Install the starter solenoid to the chassis.
2. Install the 2 (3/8 inch) bolts securing the starter solenoid to the chassis. Torque bolts to 3–4.5 N • m (35–40 in-lb).


## Starter Solenoid Installation (continued)



g302127

Figure 297

3. Install the blue and green wires to the main harness to the starter solenoid.



g302126


Figure 298



4. Install the 2 (1/2) inch nuts securing the battery cable and the starter power cable to the starter solenoid. Torque nuts to 3–4.5 N • m (35–40 in-lb).

**Note:** The battery cable side has an additional red wire for the chassis harness.

## Starter Solenoid Installation (continued)



g302125

**Figure 299**

- 
5. Install the solenoid terminal cover onto solenoid cover.
  6. Connect the battery by installing the positive battery cable first, then the negative cable to the battery.
  7. Flip the seat into the operating position.





# Foldout Drawings

## Table of Contents

Electrical Drawing Abbreviations.....	A-2
Electrical Schematic.....	A-3

# Electrical Drawing Abbreviations

The following abbreviations are used for wire harness colors on the electrical schematics and wire harness drawings in this chapter.


Abbreviation	Color
BK	Black
BR or BM	Brown
BU	Blue
GN	Green
GY	Gray
OR	Orange
PK	Pink
R or RD	Red
T	Tan
VIO	Violet
W or WH	White
Y or YE	Yellow

Numerous harness wires include a line with an alternate color. These wires are identified with the wire color followed by a / or \_ and then the line color (e.g, R/BK is a red wire with a black line; OR\_BK is an orange wire with a black line).

**Note:** The electrical harness drawings in this chapter identify both the wire color and the wire gauge. For example, 16 BK on a harness diagram identifies a 16 gauge wire with black insulation.

**Note:** A splice used in a wire harness will be identified on the wire harness diagram by SP. The manufacturing number of the splice is also identified on the wire harness diagram (e.g., SP01 is splice number 1).

# Electrical Schematic



g316875